


# OPERATION & MAINTENANCE MANUAL



DRAWING NO. 20157 REV. NC

## **MODEL TMS1000N**

**© COPYRIGHT 2015 PNEUMERCATOR CO., INC.**  
**1785 EXPRESSWAY DRIVE NORTH**  
**HAUPPAUGE, NY 11788**

TEL: (631) 293-8450  
FAX: (631) 293-8533  
<http://www.pneumercator.com>



Note: A separate INSTALLATION MANUAL is available, but NOT required for TMS1000N operation.


TABLE OF CONTENTS
-------------------

	Page
Section 1	FRONT PANEL DESCRIPTION
1.1	Overview..... 4
1.2	Display..... 5
1.3	Audible Annunciator..... 5
Section 2	OPERATION
2.1	Power-up Sequence ..... 6
2.2	Overview..... 7
2.3	View Mode ..... 8
2.4	Access Mode ..... 10
2.5	Test Mode..... 11
Section 3	ACCESS MODE MENUS
3.1	LOG ..... 12
3.1.1	Inventory Log ..... 13
3.1.2	Delivery..... 14
3.1.3	Sales..... 15
3.1.4	Thefts..... 16
3.1.5	Product Order ..... 17
3.1.6	Water Removal ..... 18
3.1.7	Alarms..... 19
3.1.8	Events..... 20
3.2	CONFIGURATION..... 21
3.2.1	Header..... 22
3.2.2	Tank..... 25
3.2.3	Probe ..... 32
3.2.4	Relay Tank..... 34
3.2.5	Relay Contact Closure ..... 36
3.2.6	Relay Sensor ..... 37
3.2.7	Relay Site ..... 38
3.2.8	Relay Mode..... 39
3.2.9	Contact Closure Input ..... 42
3.2.10	Sensor Input ..... 44
3.2.11	Inventory ..... 46
3.2.12	Theft ..... 48
3.2.13	Modem..... 50
3.2.14	Dialout..... 51
3.3	CLOCK ..... 54
3.4	INITIALIZE DATA..... 55
Appendix A	Detailed definitions of TMS Alarm, Events, and Warnings Codes ..... 56
Appendix B	Maintenance ..... 60
Appendix C	TMS Dip Switch Settings..... 62

**SECTION 1 – FRONT PANEL DESCRIPTION**

**1.1 OVERVIEW**

As illustrated in Figure 1-1 below, the TMS1000N front panel consists of an LED data display with visual alarm and mode annunciators, audible alarm annunciator, and user -friendly pushbutton controls.




DRAWING NO. 20160 REV. N/C

Figure 1-1 – Front Panel Overview

**1.2 DISPLAY**

The front panel display consists of a nine-digit, seven segment, quasi-alphanumeric super bright LED display, providing on site viewing of current inventory data, alarms, errors, report logs, as well as, set-up and configuration data. Five high intensity point LEDs annunciate alarm conditions visible up to 75 feet away from console. Five additional LED annunciators provide indication of units of measure of the currently selected display data. See figure 1-2 below.



DRAWING NO. 20161 REV. N/C

Figure 1-2 – Front Panel Display

**1.3 AUDIBLE ANNUNCIATOR**

The audible annunciator integrated into the Front Panel activates for any programmed alarm condition alerting site personnel to this fact.

## **SECTION 2 – OPERATION**

### **2.1 POWER-UP SEQUENCE**


Upon application of AC power, the TMS performs a series of tasks prior to normal operation. These include in the following sequence;

1. A self-test to verify integrity of both system program and data memories, system I/O, and data acquisition interface electronics. Display is blank during this process.
2. Retrieval and verification of configuration and set-up data.  
Display shows "**rEAd inG/ConF iG**" (Reading/Configuration).
3. System initialization, including pre-start-up calculations.  
Display shows "**SYStEm/ in it**" (System/Initialization).
4. Firmware version identification. The TMS displays the current firmware versions installed in the system. This information may be requested by Pneumercator's Technical Support department for troubleshooting purposes.
5. Visual display and audible alarm check.  
Display shows "**88888888**" (88888888) with all LEDs on, audible alarm beeps **twice**.
6. Begin normal operation, display any error messages. For a description of system error, warning and info messages, refer to **appendix A**.

Note: In cases where the TMS power has been turned off for more than one to two minutes, a power-up sequence will generate the following warning message on the display, "**UArn2 I/Pur FR iL**" Warning 21, Power Failure. This message is normal, and is just informing the user that the TMS has detected a power failure. Once acknowledged by the user by pressing any front panel pushbutton, this message will disappear from the display.

**2.2 OVERVIEW**

TMS front panel operation is defined by three user-selectable modes, View, Access, and Test, all selected using the MODE and TEST pushbuttons. See figure 2-1, System Function Tree below.



**Figure 2-1 – System Function Tree**

TMS1000N System Function Tree

**View:** The View mode is the most frequently used and the default mode of operation for the console. The View mode displays current tank data, which includes product gross, net (temperature compensated) volumes, percent of capacity, 90% ullage, product and water levels, product temperature, and product type. In addition, alarm and error conditions are annunciated in the View mode.

**Access:** The access mode provides access to all of the menus and submenus shown in Figure 2-1. In this mode the user can review report logs; review and edit system configuration data; perform initialization functions; and read or set the system clock.

**Test:** The Test mode allows visual verification of display operation, audible verification of the audible annunciator, and self-verification of critical system hardware.

**2.3 VIEW MODE**

Looking at the names assigned to the console front panel pushbuttons and display field, note that some appear in black lettering, others in orange. Only the **black**-lettered name assignments apply to the **VIEW** mode.

The seven-segment data display is formatted so that the currently selected data item appears on the right-hand side as indicated on the front panel. The LED annunciators on the left-hand side indicate alarm conditions. An alarm indicator is active when the particular LED is on.

**Pushbutton Operation:**


**MODE:** The MODE pushbutton functions both as a Display Mode Select (i.e. STEP) and a Product Name Recall. If the user depresses and holds MODE until an Audible beep is heard, the display will step to the next display item. Display items include, in order of appearance;

<u>Display Item</u>	<u>Units LEDs</u>	<u>Display Resolution</u>
Gross Volume (uncompensated)	Gallons	1 gallon
Net Volume (Temperature compensated)	Gallons, °F	1 gallon
Percent Volume	% Gallons	0.1%
Ullage	Gallons	1 gallon
Level	Inches	0.1 inches
Temperature	°F	0.1 °F

To recall the name of the product stored, depress and immediately release MODE. The product name will appear for two seconds, and then the display will revert back to displaying the currently selected data item.

**RESET:** The RESET pushbutton is used to provide an acknowledgement of the integrated audible annunciator. The RESET button will have no effect on the Alarm LEDs.

**TEST:** The Test mode allows visual verification of display operation, audible verification of the audible annunciator, and self-verification of critical system hardware.



DRAWING NO. 20159 REV. N/C

**Figure 2-2 – Front Panel Buttons**

**Front Panel Alarm Acknowledgment:**

Alarm, error or warning conditions, which occur during VIEW mode, will activate the front panel visual and audible annunciators. Depending upon user configuration programming, the user can silence the audible annunciator by momentarily pressing **any** front panel pushbutton. The visual annunciator will remain active until the alarm or error condition is eliminated. If subsequent alarm errors, or warnings occur, the audible annunciator will again be activated.



See below: Actual TMS Visual representation of Front Panel displayed items, in order of appearance:

GAL  
 %GAL  
 ULL  
 IN  
 °F

Gross Volume = 10679 Gallons

GAL  
 %GAL  
 ULL  
 IN  
 °F

Net Volume = 10596 Gallons

GAL  
 %GAL  
 ULL  
 IN  
 °F

Percent Volume = 79.7% of Capacity

GAL  
 %GAL  
 ULL  
 IN  
 °F

Ullage = 1380 Gallons

GAL  
 %GAL  
 ULL  
 IN  
 °F

Product Level = 106.8 Inches

GAL  
 %GAL  
 ULL  
 IN  
 °F

Water Level = 1.5 Inches

GAL  
 %GAL  
 ULL  
 IN  
 °F

Temperature = 72.1°F

GAL  
 %GAL  
 ULL  
 IN  
 °F

Product Name = Water

Pressing the MODE button until the BEEP, will select each item

## 2.4 ACCESS MODE

Within the **ACCESS** mode there are several levels of menus and sub-menus, as illustrated in Figure 2-1. The main menus include **LOG** reports, **CONFIG**uration, **CLOCK** read/set, and Log/Configuration memory **INIT**ialization. Note: that the LOG and CONFIG main menus contain numerous sub-menus. These sub-menus will be described in detail later in this section. The main menus are as follows:

- LoG** The LOG menu is used to review any of the various log reports generated by the TMS. The system does not allow the user to edit any of these reports.
- ConF .G** The CONFIGuration menu is used to review or edit system configuration data.
- [ locl** The CLOCK menu is used to edit system date, time, and day of the week.
- in it dRtR** The INITialization menu is used to initialize all or selected log report groups, or configuration memory.

### How to enter the ACCESS mode:

The **ACCESS** mode is entered by first pressing and holding **TEST**, and then, while still holding **TEST**, simultaneously pressing and holding **MODE**. After approximately two seconds, the **TMS** will enter the **ACCESS** mode. The display will appear as follows:



Note: The **TMS** front panel contains both black text, and orange text. Where present, the **orange** name assignments apply while in the ACCESS mode.

### Pushbutton Operation:

Within the **ACCESS** mode there are two basic types of operations that the user can perform: REVIEW and EDIT. As seen on the TMS front panel, the three right-hand pushbuttons have different functions assigned to them for REVIEW and EDIT operations.

**REVIEW MODE:** REVIEW is the normal mode of operation within the **ACCESS** mode, and is used to examine or review log, configuration, or clock data within the system. REVIEW MODE is available in all menus and sub-menus.

**STEP:** The STEP pushbutton functions both as a STEP-to-the-next-item and a Data Name Recall. If the user depresses and holds STEP until an audible beep is heard, the display will step to the next menu data item. To recall the name of the menu data item the user momentarily depresses STEP. The menu data item name will appear for two seconds, and then the display will revert back to displaying the currently selected data item.

**GROUP:** The GROUP pushbutton selects from a list of numbered menu items. This selection is generic, and refers to the fact that, depending upon which menu the user has entered, GROUP will select the next relay, leak sensor, log record, etc.

**EXAMPLE:** If the user enters a relay setup menu, GROUP will select the next relay, and the GROUP ID display field will indicate the relay number rather than a tank ID. If the user enters the INVENTORY LOG menu, which stores up to 6 records, depressing GROUP will step to the next inventory record and the GROUP ID display field will represent the inventory record number 1 through 6.

**EDIT:** The EDIT pushbutton is used to edit or change the value of the currently displayed data item. If the displayed item is a menu or sub-menu name, EDIT allows the user to change the menu. If the displayed item is system data, for example, configuration or clock data, the EDIT function is inhibited unless enabled by opening the **EDIT ENABLE** DIP switch 1 located on the main board. An audible beep informs the user when editing is inhibited. Once **EDIT ENABLE** has been opened, editing is enabled for as long as the user remains in the ACCESS mode even if the switch is returned to the closed position. For additional security, if the **TMS** is in the ACCESS mode for more than four minutes and detects no user activity on the front panel pushbuttons, the system will time out and revert back to VIEW mode. Entry back into the ACCESS mode will again require opening **EDIT ENABLE** to re-enable editing.

**EDIT MODE:** EDIT is the mode of operation within the **ACCESS** mode used to modify configuration or clock data within the system. EDIT MODE is available in the CONFIG, CLOCK, and INIT DATA sub-menus.

The names associated with pushbutton functions during edit operations are labeled in **orange** on the front panel as ► (right arrow), ▼ (down arrow), and ▲ (up arrow), as shown in Figure 2-2.

►: For numeric data, advances the blinking cursor to the right to the next digit to be changed. Pressing right arrow while at the right-most digit performs the function of ENTER, and causes the new or changed entry to be stored.

▼: Decrements the content of the blinking portion of the display. For numeric data this button is used to decrement the value of the selected digit. For alphanumeric names, ▼ decrements through a list of name selections.

▲: Increments the content of the blinking portion of the display. For numeric data this button is used to increment the value of the selected digit. For alphanumeric names, ▲ increments through a list of name selections.

## 2.5 TEST MODE

The TEST mode is initiated by depressing the TEST pushbutton. This action activates all of the front panel display LED segments and LED annunciators for visual verification, and will produce a double beep from the audible annunciator for audible verification.

**SECTION 3 – ACCESS MODE MENUS**

**3.1 LOG**

**ACCESS**

<b>LoG</b>	System reports
<b>ConF iG</b>	System configuration
<b>[ locK</b>	Set system clock
<b>in it dAtA</b>	Resets select data to initialized values
<b>rEturN</b>	Exits access menu

The LOG menus listed below are a grouping of historical or on-demand records.

			<b>Max records</b>
<b>InvEntorY</b>	Inventory	- Scheduled inventory snapshots	6
<b>dEL iVErY</b>	Deliveries	- Delivery (Product added) transactions	4
<b>SALES</b>	Sales	- Bulk sales (Product removed) transactions	4
<b>tHEFTS</b>	Thefts	- Theft incidents	2
<b>OrdErS</b>	Product Order	- On-demand product reorder report	1
<b>WAtEr</b>	Water Removal	- Water removal transaction	1
<b>ALARMS</b>	Alarms	- Probe/sensor alarms	12
<b>EvEntS</b>	Errors	- System errors/events	4

In view mode depressing TEST button first, then MODE and holding both buttons momentarily will increment the TMS into the ACCESS MODE displaying the main menu beginning as follows with LOG. Pressing the EDIT (TEST) button again would cause LOG to blink. Once LOG is blinking, pressing the ► (MODE) button will enter the LOG menu revealing the INVENTORY submenu. **The LOG menu is used to review various reports generated by the TMS.**

In the LOG menu, the system does **not** allow the user to **edit** any of these reports.

**Note:** Three types of entries require the user to input programming data when configuring the TMS menus. It is mentioned here, to help the user interpret data displayed in the Log menus. This information below will be explained again in the CONFIG section of the manual.

**Entry Type:** Either a numeric value or a list of choices designated by the system.

**Range Limits:** Selects and enters a numeric value within a fixed boundary, set by the system.

**Default/Initialized value:** If not user programmed, this entry, value or term, will be set by the system.

To select and step through other records while in the LOG menu, pressing the ▲ (TEST) button at the flashing term such as INVENTORY will increment the system to the next menu. i.e. DELIVERY, then SALES, etc. The ▼ (RESET) button at the flashing term such as INVENTORY will decrement the system to the next menu. i.e. RETURN, then EVENTS, etc.

**3.1.1 INVENTORY LOG**

**Inventory** Inventory This menu displays a snapshot of the stored inventory data for each tank, which the user programs, at up to three scheduled capture times a day and selectable for each day of the week. An automatic hardcopy report can be generated if the TMS is linked to a PC utilizing the TMS Communicator software package. The user may also step through and view the record manually, utilizing the TMS front panel pushbuttons. The system has the capacity to store, beginning with the most recent, up to 6 inventory records. Inventory log reports will contain the following data: Date, Time, Tank Name, Product Type, Tank ID, Product Height, Gross Volume, Net Volume, Percent Volume, Ullage, and Temperature.

<b>nn-dd</b>	<u>Month - Day</u>	Month and Day of this inventory record. An empty record will have a 00-00.
<b>HH' nn</b>	<u>Hour-Minute</u>	Hour and Minute of the Inventory record. (time stored in 24 hr. format) Example 12'00 = 12 Noon; 23'59 = 11:59 PM; 00'00 = Midnight
<b>tRnk NAME</b>	<u>Tank Name</u>	Tank Name assigned by user.
<b>Prod TYPE</b>	<u>Product Type</u>	Tank Product Type assigned by user.
<b>tRnk id</b>	<u>Tank ID Number</u>	2-digit numeric value assigned by user.
<b>Prod Ht</b>	<u>Product Height</u>	Product level (in/mm).
<b>Gr Vol</b>	<u>Gross Volume</u>	Gross Volume (gal/L).
<b>NET Vol</b>	<u>Net Volume</u>	Net or Temperature Compensated Volume (gal/L).
<b>P Vol</b>	<u>Percent Volume</u>	Percentage of Total Volume.
<b>ULLAGE</b>	<u>Ullage</u>	The complement difference between the actual fuel volume and volume in which the tank can be filled to the Ullage limit (set in the HEADER menu) in Gross Volume (Gr Vol). Example: A 10,000 gallon tank is 8000 gallons full - System will store a 90% Ullage record of 1000 gallons.
<b>tEnP</b>	<u>Temperature</u>	Product Temperature (°F/°C).
<b>rEturN</b>	<u>Return</u>	*Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the LOG submenu showing INVENTORY.  *Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the INVENTORY menu showing <b>nn-dd</b>

**3.1.2 DELIVERY LOG**

**DELIVERY Delivery** This menu displays a snapshot of the stored delivery data for each tank, which the system will automatically log and record as a inventory increase when a delivery to a tank has occurred. An automatic hardcopy report can be generated if the TMS is linked to a PC utilizing the TMS Communicator software package. The user may also step through and view the record manually, utilizing the TMS front panel pushbuttons. The system has the capacity to store, beginning with the most recent, up to 4 delivery records. Delivery log reports will contain the following data: Date, Time, Tank Name, Product type, Tank ID, Start Product Height, End Product Height, Start Temperature, End Temperature, End Gross Volume, Start Gross Volume, Gross Volume Increase, End Net Volume, Start Net Volume, Net Volume Increase.

<b>mm-dd</b>	<u>Month - Day</u>	Month and Day of this delivery record. An empty record will have a 00-00.
<b>HH' mm</b>	<u>Hour-Minute</u>	Hour and Minute of the delivery record. (time stored in 24 hr. format) Example 12'00 = 12 Noon; 23'59 = 11:59 PM; 00'00 = Midnight
<b>tANK NAME</b>	<u>Tank Name</u>	Tank Name assigned by user.
<b>Prod TYPE</b>	<u>Product Type</u>	Tank Product Name assigned by user.
<b>tANK ID</b>	<u>Tank ID Number</u>	2-digit numeric value assigned by user.
<b>bEG in Ht</b>	<u>Begin Height</u>	Pre-delivery Product level (in/mm).
<b>End Ht</b>	<u>End Height</u>	Post-delivery Product level (in/mm).
<b>bEG tEnP</b>	<u>Beginning Temperature</u>	Pre-delivery Product Temperature in degrees in Fahrenheit (°F/°C).
<b>End tEnP</b>	<u>End Temperature</u>	Post-delivery Product Temperature in degrees in Fahrenheit (°F/°C).
<b>Gr End</b>	<u>Gross End Volume</u>	Post-delivery Gross Volume (gal/L).
<b>Gr bEG in</b>	<u>Gross Begin Volume</u>	Pre-delivery Gross Volume (gal/L).
<b>Gr dIFF</b>	<u>Gross Difference</u>	Difference between the beginning and ending Gross Volume (gal/L).
<b>NEt End</b>	<u>Net End Volume</u>	Post-delivery Net or Temperature Compensated Volume (gal/L).
<b>NEt bEG in</b>	<u>Net Begin Volume</u>	Pre-delivery Net or Temperature Compensated Volume (gal/L).
<b>NEt dIFF</b>	<u>Net Difference</u>	Difference between the beginning and ending Net volume (gal/L).
<b>rEtURN</b>	<u>Return</u>	*Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the LOG submenu showing DELIVERY.  *Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the DELIVERY menu showing <b>mm-dd</b>

### 3.1.3 SALES LOG

**SALES**      Sales      This menu displays a snapshot of the stored bulk sales data for each tank, which the system will automatically log and record as a inventory decrease when a withdrawal from a tank has occurred. An automatic hardcopy report can be generated if the TMS is linked to a PC utilizing the TMS Communicator software package. The user may also step through and view the record manually, utilizing the TMS front panel pushbuttons. The system has the capacity to store, beginning with the most recent, up to 4 sales records. Sales log records will contain the following data: Date, Time, Tank Name, Product Type, Tank ID, Start Product Height, End Product Height, Start Temperature, End Temperature, Start Gross Volume, End Gross Volume, Gross Volume decrease, Start Net Volume, End Net Volume, Net Volume decrease.

<b>nn-dd</b>	<u>Month - Day</u>	Month and Day of this sales record. An empty record will have a 00-00.
<b>HH' nn</b>	<u>Hour-Minute</u>	Hour and Minute of the sales record. (time stored in 24 hr. format) Example 12 PM = 12'00; 23'59 = 11:59 PM; 00'00 = Midnight
<b>tRnE nRnE</b>	<u>Tank Name</u>	Tank Name assigned by user.
<b>Prod tYPE</b>	<u>Product Type</u>	Tank Product Name assigned by user.
<b>tRnE id</b>	<u>Tank ID Number</u>	2-digit numeric value assigned by user.
<b>bE9 in Ht</b>	<u>Begin Height</u>	Pre-sales Product level (in/mm).
<b>End Ht</b>	<u>End Height</u>	Post-sales Product level (in/mm).
<b>bE9 tEnP</b>	<u>Beginning Temperature</u>	Pre-sales Product Temperature (°F/°C).
<b>End tEnP</b>	<u>End Temperature</u>	Post-sales Product Temperature (°F/°C).
<b>Gr bE9 in</b>	<u>Gross Begin Volume</u>	Pre-sales Gross Volume (gal/L).
<b>Gr End</b>	<u>Gross End Volume</u>	Post-sales Gross Volume (gal/L).
<b>Gr d iFF</b>	<u>Gross Difference</u>	Difference between the beginning and ending Gross Volume (gal/L).
<b>nEt bE9 in</b>	<u>Net Begin Volume</u>	Pre-sales Net or Temperature Compensated Volume (gal/L).
<b>nEt End</b>	<u>Net End Volume</u>	Post-sales Net or Temperature Compensated Volume (gal/L).
<b>nEt d iFF</b>	<u>Net Difference</u>	Difference between the beginning and ending Net Volume (gal/L).
<b>rEturN</b>	<u>Return</u>	*Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the LOG submenu showing SALES.  *Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the SALES menu showing <b>nn-dd</b>

**3.1.4 THEFTS LOG**

**THEFTS**      Thefts      This menu displays a snapshot of the stored theft data for each tank. Logged capture times, which the user programs are based on the facility scheduled closed hours. The system will automatically log and record an inventory decrease as a fuel theft while the station is closed. An automatic hardcopy report can be generated if the TMS is linked to a PC utilizing the TMS Communicator software package. The user may also step through and view the record manually, utilizing the TMS front panel pushbuttons. The system has the capacity to store, beginning with the most recent, up to 2 theft records. Theft log reports will contain the following data: Date, Time, Tank Name, Product Type, Tank ID, Start Product Height, End Product Height, Start Temperature, End Temperature, Start Gross Volume, End Gross Volume, Gross Volume decrease, Start Net Volume, End Net Volume, Net Volume decrease.

<b>nn-dd</b>	<u>Month - Day</u>	Month and Day of this theft record. An empty record will have a 00-00.
<b>HH' mm</b>	<u>Hour-Minute</u>	Hour and Minute of the theft record. (time stored in 24 hr. format) Example 12 PM = 12'00; 23'59 = 11:59 PM; 00'00 = Midnight
<b>tRnk nRnE</b>	<u>Tank Name</u>	Tank Name assigned by user.
<b>Prod tYPE</b>	<u>Product Type</u>	Tank Product Name assigned by user.
<b>tRnk id</b>	<u>Tank ID Number</u>	2-digit numeric value assigned by user.
<b>bEG in Ht</b>	<u>Begin Height</u>	Pre-theft Product level (in/mm).
<b>End Ht</b>	<u>End Height</u>	Post-theft Product level (in/mm).
<b>bEG tEnP</b>	<u>Beginning Temperature</u>	Pre-theft Product Temperature (°F/°C).
<b>End tEnP</b>	<u>End Temperature</u>	Post-theft Product Temperature (°F/°C).
<b>Gr bEG in</b>	<u>Gross Begin Volume</u>	Pre-theft Gross Volume (gal/L).
<b>Gr End</b>	<u>Gross End Volume</u>	Post-theft Gross Volume (gal/L).
<b>Gr d iFF</b>	<u>Gross Difference</u>	Difference between the beginning and ending Gross Volume (gal/L).
<b>NEt bEG in</b>	<u>Net Begin Volume</u>	Pre-theft Net or Temperature compensated Volume (gal/L).
<b>NEt End</b>	<u>Net End Volume</u>	Post-theft Net or Temperature compensated Volume (gal/L).
<b>NEt d iFF</b>	<u>Net Difference</u>	Difference between the beginning and ending Gross Volume (gal/L).
<b>rEturn</b>	<u>Return</u>	*Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the LOG submenu showing THEFTS.  *Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the THEFTS menu showing <b>nn-dd</b>



### 3.1.5 PRODUCT ORDER LOG

**Order-5**      Product Order      A manually generated report for the tank at the moment the log record is accessed. The user will utilize this information to determine average daily fuel usage and date and the amount of fuel to order for the next delivery. In addition to the system capturing this data, an automatic hardcopy report can be generated if the TMS is linked to a PC utilizing the TMS Communicator software package. The user may also step through and view the record manually, utilizing the TMS front panel pushbuttons. Product Order log reports will contain the following data: Date, Time, Tank Name, Product Type, Tank ID, Delivery Date, Delivery Amount, Start Gross Volume, End Gross Volume, Gross Volume Usage, Days of Usable Fuel, Average Daily Usage, Usable Fuel remaining, Elapsed days since the last delivery, Ullage or Order amount.

<b>nn-dd</b>	<u>Month - Day</u>	Month and Day of this product order record. An empty record will have a 00-00.
<b>HH' nn</b>	<u>Hour-Minute</u>	Hour and Minute of the order record. (time stored in 24 hr. format) Example 12'00 = 12 Noon; 23'59 = 11:59 PM; 00'00 = Midnight
<b>tANK NAME</b>	<u>Tank Name</u>	Tank Name assigned by user.
<b>Prod TYPE</b>	<u>Product Type</u>	Tank Product Name assigned by user.
<b>tANK ID</b>	<u>Tank ID Number</u>	2-digit numeric value assigned by user.
<b>dEL DATE</b>	<u>Delivery Date</u>	Date of Last Delivery.
<b>dEL AMt</b>	<u>Delivery Amount</u>	Amount of fuel delivered (gal/L).
<b>Gr BEG in</b>	<u>Gross Begin Volume</u>	Pre-delivery Gross Volume (gal/L).
<b>Gr End</b>	<u>Gross End Volume</u>	Post-delivery Gross Volume (gal/L).
<b>tOTAL USE</b>	<u>Gross Difference</u>	Gross amount of fuel used since last delivery (gal/L).
<b>dAYS</b>	<u>Days</u>	Elapsed days since the last delivery.
<b>dAILY USE</b>	<u>Daily Use</u>	Average daily usage in Gross Volume (gal/L), based on the number of days since last delivery. For example, if 6000 gallons were used over 30 days, the average daily use would be 200 gallons.
<b>USABLE</b>	<u>Usable</u>	The current usable volume (gal/L) at 90% of total tank capacity.
<b>dAYS LEFT</b>	<u>Days Left</u>	This is how many days of fuel supply are remaining, based on the average daily usage and current usable volume.
<b>ULLAGE</b>	<u>Ullage</u>	Maximum product order amount in Gross Volume (gal/L) calculated based on current ullage percentage.
<b>rEtURN</b>	<u>Return</u>	*Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the LOG submenu showing ORDERS.  *Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the ORDERS menu showing <b>nn-dd</b>

**3.1.6 WATER REMOVAL LOG**

**Water Removal** The Water Removal menu displays an automatically generated report for each tank after the removal of water has taken place. In addition to the system capturing this data, an automatic hardcopy report can be generated if either, optional printer is installed, or if the TMS is linked to a PC utilizing the TMSCOMM communicator software package. The user may also step through and view the record manually, utilizing the TMS front panel pushbuttons. The system has the capacity to store, beginning with the most recent, up to 12 Water Removal records. Water Removal log reports will contain the following data: Date, Time, Tank Name, Product Type, Tank ID, Pre-report Product Volume, Pre-report H2o Volume, Pre-report Total (Product and H2o) Volume, Post-report Product Volume, Post-report H2o Volume, Post-report Total (Product and H2o) Volume, Post-report (Product and H2o) Percent Volume, Post-report Percent Volume, Post-report 90% Ullage or the (Order amount).

<b>nn-dd</b>	<u>Month - Day</u>	Month and Day of this product order record. An empty record will have a 00-00.
<b>HH' nn</b>	<u>Hour-Minute</u>	Hour and Minute of the order record. (time stored in 24 hr. format) Example 12'00 = 12 Noon; 23'59 = 11:59 PM; 00'00 = Midnight
<b>tAnE nAnE</b>	<u>Tank Name</u>	Tank Name assigned by user.
<b>Prod tYPE</b>	<u>Product Type</u>	Tank Product Name assigned by user.
<b>tAnE id</b>	<u>Tank Ident</u>	2-digit numeric value assigned by user.
<b>Prod bEG i</b>	<u>Product Begin Volume</u>	Initial Gross Volume (gal/L) for Product in the indicated tank excluding Water, before the water removal process starts.
<b>h2o bEG in</b>	<u>Water Begin Volume</u>	Initial Gross Volume (gal/L) for Water in the indicated tank excluding Product, before the water removal process starts.
<b>bEG totAL</b>	<u>Gross Begin Volume</u>	Initial Gross Volume (gal/L) for both Product and Water in the indicated tank, before the water removal process starts.
<b>Prod End</b>	<u>Product End Volume</u>	End Gross Volume (gal/L) for Product in the indicated tank excluding Water, before the water removal process starts.
<b>h2o End</b>	<u>Water End Volume</u>	End Gross Volume (gal/L) for Water in the indicated tank excluding Product, before the water removal process starts.
<b>End totAL</b>	<u>Gross End Volume</u>	End Gross Volume (gal/L) for both Product and Water in the indicated tank, before the water removal process starts.
<b>P Vol</b>	<u>Percent End Volume</u>	Total Product and Water Volume for the indicated tank in Percent, after the water removal process has been completed.
<b>ULLAGE</b>	<u>Ullage</u>	Maximum product order amount for the indicated tank in Gross Volume (gal/L) calculated at 90% of tank capacity, after the water removal process has been completed.
<b>rEturn</b>	<u>Return</u>	*Pressing the Test/Edit button at Return decrements the TMS back to the top of that submenu to repeat the <b>Water Removal</b> cycle again. <b>Water Removal</b>  *Pressing the Mode/Step button at the Return decrements the TMS back out to the top of the <b>Water Removal</b> TMS main menu. <b>nn-dd</b>

### 3.1.7 ALARMS LOG

**ALARMS**      Alarms      This menu displays a snapshot of the stored alarm data, which the system will automatically log and record as a system, tank, or external leak alarm(s). An automatic hardcopy report can be generated if the TMS is linked to a PC utilizing the TMS Communicator software package. The user may also step through and view the record manually, utilizing the TMS front panel pushbuttons. The system has the capacity to store, beginning with the most recent, up to 12 alarm records. Alarm log reports will contain the following data: Date, Time, Alarm, Group Number, Alarm ID, and Detail. The TMS will report Sensors, 6 Product set points, 4 temperature set points, Non-IS Contact Closure Input, Theft, System Error, and Power Recovery.

<b>nn-dd</b>	<u>Month - Day</u>	Month and Day of this alarm record. An empty record will have a 00-00.
<b>HH' nn</b>	<u>Hour-Minute</u>	Hour and Minute of the alarm record. (time stored in 24 hr. format) Example 12'00 = 12 Noon; 23'59 = 11:59 PM; 00'00 = Midnight
<b>ALARn</b>	<u>Alarm</u>	Specific alarm condition assigned by TMS.
<b>Group Nun</b>	<u>Group Number</u>	A numeric alarm Identification code.
<b>ALARn id</b>	<u>Alarm Ident</u>	Designates specific alarm as system, tank, or external devices.
<b>dEtAL</b>	<u>Detail</u>	Designates the condition as an Alarm, Warning, Information condition, or Error.
<b>rEtURN</b>	<u>Return</u>	*Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the LOG submenu showing ALARMS.  *Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the ALARMS menu showing <b>nn-dd</b>

**For description of Alarms, Warnings, or Errors, see Appendix A.**

**3.1.8 EVENTS LOG**

**EvEnt5**      Events      This menu displays a snapshot of the stored event data for each tank, which the system will automatically log and record as a system Error, Warning, or TMS Information Condition. An automatic hardcopy report can be generated if the TMS is linked to a PC utilizing the TMS Communicator software package. The user may also step through and view the record manually, utilizing the TMS front panel pushbuttons. The system has the capacity to store, beginning with the most recent, up to 4 event records. Event log reports may contain any combination of the following data: Date, Time, Error Number, Event ID, and Detail.

<b>nn-dd</b>	<u>Month - Day</u>	Month and Day of this alarm record. An empty record will have a 00-00.
<b>HH' nn</b>	<u>Hour-Minute</u>	Hour and Minute of the alarm record. (time stored in 24 hr. format) Example 12'00 = 12 Noon; 23'59 = 11:59 PM; 00'00 = Midnight
<b>Error nn</b>	<u>Error Number</u>	A numeric 2-digit error Identification code.
<b>EvEnt id</b>	<u>Event Ident</u>	Designates specific condition of event.
<b>dEtR iL</b>	<u>Detail</u>	Designates specific event as a Error, Warning, or TMS Information Condition.
<b>rEturN</b>	<u>Return</u>	*Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the LOG submenu showing EVENTS.  *Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the EVENTS menu showing <b>nn-dd</b>

**For description of Alarms, Warnings, or Errors, see Appendix A.**

### 3.2 CONFIGURATION

```
ACCESS      LOG
            CONF
            EDIT
            INIT DIAL
            RETURN
```

In view mode depressing TEST button first, then MODE and holding both buttons momentarily will increment the TMS into the ACCESS MODE displaying the main menu beginning as follows with LOG. Pressing the EDIT (TEST) button again would cause LOG to blink. Once LOG is blinking, press the ▲ (TEST) button to go to the CONFIG menu. Once CONFIG is blinking, pressing the ► (MODE) button will enter the CONFIG menu revealing the HEADER submenu.

**The CONFIG menu is used to review or edit system configuration data.**

**Note:** Three types of entries require the user to input programming data when configuring the TMS menus. It is mentioned here, to help the user interpret data displayed in the CONFIG menus. This information below will be explained again in the CLOCK section of the manual.

**Entry Type:** Either a numeric value or a list of choices designated by the system.

**Range Limits:** Selects and enters a numeric value within a fixed boundary, set by the system.

**Default/Initialized value:** If not user programmed, this entry, value or term, will be set by the system.

To select and step through other records while in the CONFIG menu, pressing the ▲ (TEST) button at the flashing term such as HEADER will increment the system to the next menu. i.e. TANK, then PROBE, etc. The ▼ (RESET) button at the flashing term such as HEADER will decrement the system to the next menu. i.e. RETURN, then DIAL OUT, etc.

3.2.1 HEADER

CONF 19

<b>HEAdEr</b>	<b>Header - Global System Settings</b>
<b>tRnk</b>	Tank - Programming setup
<b>PrObE</b>	Probe - Programming setup
<b>rELY tRnk</b>	Relay Tank - Programming tank related alarms to control relays
<b>rELY cc</b>	Relay Contact Closure - Programming contact closure inputs to control relays
<b>rELY SEnS</b>	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
<b>rELY S tE</b>	Relay Site - Programming site related alarms/errors to control relays
<b>rELY ModE</b>	Relay Mode - Status of relay operation
<b>cc inPut</b>	Contact Closure Input
<b>SEnSr inP</b>	Sensor Input
<b>InuEntorY</b>	Tank Inventory Log Data setup
<b>tHEft</b>	Theft - Detection (Hours of operation)
<b>ModEr</b>	Modem Communications - Setup
<b>d iRL out</b>	Auto-Dial out - Setup for selected Alarms or Tank information
<b>rEturN</b>	Return - Exits CONFIG menu

**HEAdEr**      Header      This menu provides access to global TMS settings. It is essential that these parameters are qualified prior to further TMS programming.

**Acc CodE**      Access Code: When security is enabled via DIP switch 4 (see Appendix B), this code is required to communicate with the TMS. This code is also used when attempting to upload firmware into the TMS.  
 Entry Type: 6-digit numeric  
 Range Limits: 000000-999999  
 Default/Initialized value **000000**

**SECur itY**      Security: When security is enabled via DIP switch 4 (see Appendix B), this setting selects which communications interfaces implement the security feature.  
 Entry Type: select list  
 Range Limits: N/A  
 Default/Initialized value **SEr iRL**  
 Item List:      **SEr iRL** = RS-232 Serial Port      **ModEr** = Modem  
                  **both** = Both RS-232 and Modem

**Un it id**      Unit ID: Useful for differentiating between multiple TMS systems at the same site. User may assign up to 100 unique numbers per site.  
 Entry Type: 2-digit numeric  
 Range Limits: 00-99  
 Default/Initialized value: **00**

**S tE id**      Site ID: Useful as a means for identifying more than one site. User can assign up to 100000 unique site ID numbers.  
 Entry Type: 3-digit numeric  
 Range Limits: 00000-99999  
 Default/Initialized value: **00000**

**dSP ModE**      Default Display Mode: This entry selects the default mode in which the TMS will display data while in the normal viewing mode. The TMS will automatically revert back to the default mode (**Gr Vol**) gross volume display after a four minute time out is recognized for non-utilization of the front panel pushbuttons..  
 Entry Type: select list  
 Range Limits: N/A  
 Default/Initialized value: **Gr Vol**  
 Item List:      **Gr Vol** = Gross Volume      **LEUEL** = Units of measure  
                  **PctVol** = Percent Gross Volume      **nEtVol** = Net Volume

- baud rAtE**      Baud Rate: This entry allows the user to select the baud rate for the TMS RS-232 serial communications port.  
 Entry Type: select list  
 Range Limits: 1.2K-38.4K (1,200 - 38,400)  
 Default/Initialized value: ~~960~~  
 Item List:    ~~960~~ 9600 Baud            ~~3840~~ 38,400 Baud    ~~120~~ 1200 Baud  
                  ~~240~~ 2400 Baud            ~~480~~ 4800 Baud
- SEr iALFnt**      Serial Format: This entry allows the user to select the parity, data bits, and stop bit for the RS-232 serial communications port.  
 Entry Type: select list  
 Range Limits: N/A  
 Default/Initialized value: ~~n-8-1~~  
 Item List:    ~~n-8-1~~ No Parity, 8 Data Bits, 1 Stop Bit  
                  ~~E-7-1~~ Even Parity, 7 Data Bits, 1 Stop Bit  
                  ~~o-7-1~~ Odd Parity, 7 Data Bits, 1 Stop Bit
- SP1 LEd**      SP1 LED: This entry allows the user to assign one of the six set points to one of the three set point LEDs. This would result in this set point being defined as an alarm set point.  
 Entry Type: select list  
 Range Limits: N/A  
 Default/Initialized value: ~~H H ,9h~~  
 Item List:    ~~H H ,9h~~ High High    ~~H ,9h~~ High            ~~Lo~~ Low  
                  ~~LoLo~~ Low Low            ~~Cr iLo~~ Critical Low    ~~Cr iH ,~~ Critical High
- SP2 LEd**      SP2 LED: This entry allows the user to assign one of the six set points to one of the three set point LEDs. This would result in this set point being defined as an alarm set point.  
 Entry Type: select list  
 Range Limits: N/A  
 Default/Initialized value: ~~H ,9h~~  
 Item List:    ~~H ,9h~~ High            ~~Lo~~ Low            ~~LoLo~~ Low Low  
                  ~~Cr iLo~~ Critical Low    ~~Cr iH ,~~ Critical High    ~~H H ,9h~~ High High
- SP3 LEd**      SP3 LED: This entry allows the user to assign one of the six set points to one of the three set point LEDs. This would result in this set point being defined as an alarm set point.  
 Entry Type: select list  
 Range Limits: N/A  
 Default/Initialized value: ~~Lo~~  
 Item List:    ~~Lo~~ Low            ~~LoLo~~ Low Low            ~~Cr iLo~~ Critical Low  
                  ~~Cr iH ,~~ Critical High    ~~H H ,9h~~ High High    ~~H ,9h~~ High
- SALe En**      Sale Enable: When enabled, Allows system to detect and log bulk sales when the following conditions are valid:  
 1. Station is open for business, according to hours of operation programmed in THEFT DETECT submenu.  
 2. Withdrawal exceeds MINIMUM LOG VOLUME programmed in TANK.  
 Entry Type: select list  
 Range Limits: (Yes, No)  
 Default/Initialized value: ~~no~~
- Horn dELAY**      Horn Delay: The ability to have the TMS automatically acknowledge the integrated horn after a delay of 1-9 minutes. Although the horn is silenced, the LED for that condition will continue to be visually illuminated until alarm condition is satisfied. This feature can be disabled by selecting NONE.  
 Entry Type: select list  
 Range Limits: (None, 1-9)  
 Default/Initialized value: ~~nonE~~

- Ullage Limit**      Ullage Limit: Defines the maximum percentage of Gross Volume that is intended to occupy the tank. The Ullage value reported by the TMS represents the Gross Gallons that can be added to the tank to reach that percentage of Gross Volume.  
Entry Type: select list  
Range Limits: (85%, 90%, 95%, 100%)  
Default/Initialized value: **90**
- Daylight Savings Time Enable**      Daylight Savings Time Enable: Enables automatic clock adjustment based on the current U.S. Daylight Savings Time rules.  
Entry Type: select list  
Range Limits: (Yes, No)  
Default/Initialized value: **no**
- Return**      Return  
\*Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the CONFIG submenu showing HEADER.  
  
\*Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the HEADER menu showing ACCESS CODE.



### 3.2.2 TANK

**CONF 19**

<b>HEAdEr</b>	Header - Global System Settings
<b>tAnT</b>	<b>Tank - Programming setup</b>
<b>PrObE</b>	Probe - Programming setup
<b>rELY tAnT</b>	Relay Tank - Programming tank related alarms to control relays
<b>rELY cC</b>	Relay Contact Closure - Programming contact closure inputs to control relays
<b>rELY SEnS</b>	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
<b>rELY S tE</b>	Relay Site - Programming site related alarms/errors to control relays
<b>rELY ModE</b>	Relay Mode - Status of relay operation
<b>cC inPut</b>	Contact Closure Input
<b>SEnSr inP</b>	Sensor Input
<b>InuEntorY</b>	Tank Inventory Log Data setup
<b>tHEFT</b>	Theft - Detection (Hours of operation)
<b>ModEm</b>	Modem Communications - Setup
<b>d iAL out</b>	Auto-Dial out - Setup for selected Alarms or Tank information
<b>rEturN</b>	Return - Exits CONFIG menu

**tAnT** The TANK menu in CONFIG lets the user configure tank-specific details including: Tank ID, Product and Temperature Alarm Setpoints, and Tank Geometry.

**tAnT En** Tank Enable: This entry identifies whether the tank is active and has a probe in service.  
 Entry Type: select list  
 Range Limits: (Yes, No)  
 Default/Initialized value: **no**

**tAnT nAnE** Tank Name This entry allows the user to select a generic name for fuel contents.  
 User selects the Tank Name for each enabled tank. See table below.  
 Entry Type: select list  
 Range Limits: N/A  
 Default/Initialized value: **9AS**

<b>9AS</b> = Gas	<b>d iESeL</b> = Diesel	<b>FUEL</b> = Fuel
<b>2 O iL</b> = #2 Fuel Oil	<b>3 O iL</b> = #3 Fuel Oil	<b>4 O iL</b> = #4 Fuel Oil
<b>5 O iL</b> = #5 Fuel Oil	<b>6 O iL</b> = #6 Fuel Oil	<b>O iL</b> = Oil
<b>WAStE</b> = Waste Oil	<b>tEro</b> = Kerosene	<b>Av 9AS</b> = Aviation Gas
<b>Av 100</b> = Aviation 100	<b>100 LL</b> = 100 Low Lead	<b>JEt</b> = Jet Fuel
<b>JEt A</b> = Jet A Fuel	<b>JP4</b> = JP4	<b>JP5</b> = JP5
<b>JP8</b> = JP8	<b>LoSuLF</b> = Low Sulfur Diesel	<b>Hi SuLF</b> = Hi Sulfur Diesel
<b>rd dSL</b> = Red Diesel	<b>CL dSL</b> = Clear Diesel	<b>NoLEAd</b> = No Lead
<b>PrEn</b> = Premium	<b>PLUS</b> = Plus	<b>MidGrd</b> = MidGrade
<b>rEgULr</b> = Regular	<b>rE9 1</b> = Regular 1	<b>rE9 2</b> = Regular 2
<b>rE9 3</b> = Regular 3	<b>rE9 4</b> = Regular 4	<b>SuPEr</b> = Super
<b>SuPEr 1</b> = Super 1	<b>SuPEr 2</b> = Super 2	<b>SuPEr 3</b> = Super 3
<b>SuPEr 4</b> = Super 4	<b>SPUnL</b> = Super Unleaded	<b>ToLuEn</b> = Toluene
<b>HydO iL</b> = Hydraulic Oil	<b>TrbO iL</b> = Turbine Oil	<b>UStH2o</b> = Waste Water
<b>LubE</b> = Lube Oil	<b>tRAnS</b> = Transmission Oil	<b>MoTor</b> = Motor Oil
<b>OU SEP</b> = Oil/Water Separator	<b>GLYcol</b> = Glycol	<b>MEt</b> = MEK/Methyl Ethyl Ketone
<b>XyLEnE</b> = Xylene	<b>nAPtHA</b> = Naptha	<b>Ar 100</b> = Aromatic 100
<b>iSobut</b> = Isobutylaldehyde	<b>WAtEr</b> = Water	<b>O iL -PL</b> = Oil-Plasticizer
<b>MEtAnL</b> = Methanol	<b>rEcYcd</b> = Recycled Oil	<b>U r9 in</b> = Virgin Oil
<b>Mo9AS</b> = Mogas	<b>EtHAnL</b> = Ethanol	<b>EtH 10</b> = 10% Ethanol
<b>EtH 15</b> = 15% Ethanol	<b>EtH 20</b> = 20% Ethanol	<b>EtH 85</b> = 85% Ethanol
<b>USEr</b> = User-defined Tank Name		

**TANK ID** Tank ID Number: This entry selects a unique tank identification number to any 2-digit numerical value up to 99.  
 Entry Type: 2-digit numeric  
 Range Limits: 01-99  
 Default/Initialized value: **01**

**VOL MODE** Volume Mode: This entry allows the user to select one of two modes which is dependent on tank capacity. The BY 1 mode is selected for tank capacities of less than 1 million gallons. The BY 10 mode is selected for Tank capacities 1 million gallons and higher. All other settings programmed in gallons would be multiplied by 10. Example: A 2,000,000 gallon capacity would be entered as 200,000 in the CONFIG, TANK CAPACITY menu.  
 Entry Type: select list  
 Range Limits: (by 1, by 10)  
 Default/Initialized value: **BY 1**

**Prod TYPE** Product Type This entry allows the user to select tank contents. User selects the Product Type for each enabled tank. See table below.  
 Entry Type: select list  
 Range Limits: N/A  
 Default/Initialized value: **87 Octane**

**Note: For products not listed - Consult Factory**

<b>87 oct</b> = 87 Octane	<b>89 oct</b> = 89 Octane	<b>91 oct</b> = 91 Octane
<b>92 oct</b> = 92 Octane	<b>93 oct</b> = 93 Octane	<b>94 oct</b> = 94 Octane
<b>95 oct</b> = 95 Octane	<b>dIESEL</b> = Diesel	<b>KEro</b> = Kerosene
<b>No 2</b> = #2 Fuel Oil	<b>No 4</b> = #4 Fuel Oil	<b>No 6</b> = #6 Fuel Oil
<b>WASTE</b> = Waste Oil	<b>Av GAS</b> = Aviation Gas	<b>Av 100</b> = Aviation 100
<b>100 LL</b> = 100 Low Lead	<b>JET A</b> = Jet A Fuel	<b>JP4</b> = JP4
<b>JP5</b> = JP5	<b>JP8</b> = JP8	<b>ToluEn</b> = Toluene
<b>LubE</b> = Lube Oil	<b>TRAN5</b> = Transmission Oil	<b>Motor</b> = Motor Oil
<b>GLYcol</b> = Glycol	<b>MEt</b> = MEK/Methyl Ethyl Ketone	<b>XYLEnE</b> = Xylene
<b>NApHA</b> = Naptha	<b>Ar 100</b> = Aromatic 100	<b>ISobut</b> = Isobutyraldehyde
<b>WATER</b> = Water	<b>Oil-PL</b> = Oil-Plasticizer	<b>MEthnL</b> = Methanol
<b>ChEn</b> = Chemical	<b>EtHANL</b> = Ethanol	<b>EtH 10</b> = 10% Ethanol
<b>EtH 15</b> = 15% Ethanol	<b>EtH 20</b> = 20% Ethanol	<b>EtH 85</b> = 85% Ethanol

**SP Cr tH** Set Point – Critical High Volume: This is one of the three programmable overage alarms for detecting a percentage of gross volume at or above the programmed threshold. This will only generate an alarm when associated with one of the numbered set point LEDs. It can always be used to control an integrated relay.  
 Entry Type: 3 digit numeric, %  
 Range Limits: 0-99.9%  
 Default/Initialized value: **980**

**SP H H** Set Point – High High Volume: This is one of the three programmable overage alarms for detecting a percentage of gross volume at or above the programmed threshold. This will only generate an alarm when associated with one of the numbered set point LEDs. It can always be used to control an integrated relay.  
 Entry Type: 3 digit numeric, %  
 Range Limits: 0-99.9%  
 Default/Initialized value: **950**

**SP H Sh** Set Point – High Volume: This is one of the three programmable overage alarms for detecting a percentage of gross volume at or above the programmed threshold. This will only generate an alarm when associated with one of the numbered set point LEDs. It can always be used to control an integrated relay.  
 Entry Type: 3 digit numeric, %  
 Range Limits: 0-99.9%  
 Default/Initialized value: **900**

- SP Lo**      Set Point – Low Volume: This is one of the three programmable underage alarms for detecting a percentage of gross volume at or below the programmed threshold. This will only generate an alarm when associated with one of the numbered set point LEDs. It can always be used to control an integrated relay.  
Entry Type: 3 digit numeric, %  
Range Limits: 0-99.9%  
Default/Initialized value: **200**
- SP LoLo**      Set Point – Low Low Volume: This is one of the three programmable underage alarms for detecting a percentage of gross volume at or below the programmed threshold. This will only generate an alarm when associated with one of the numbered set point LEDs. It can always be used to control an integrated relay.  
Entry Type: 3 digit numeric, %  
Range Limits: 0-99.9%  
Default/Initialized value: **150**
- SP Cr tLo**      Set Point – Critical Low Volume: This is one of the three programmable underage alarms for detecting a percentage of gross volume at or below the programmed threshold. This will only generate an alarm when associated with one of the numbered set point LEDs. It can always be used to control an integrated relay.  
Entry Type: 3 digit numeric, %  
Range Limits: 0-99.9%  
Default/Initialized value: **120**
- Cr tHHorn**      Horn – Critical High Volume Set Point: Enables the audible annunciator for the Critical High Set Point if associated with one of the numbered set point LEDs.  
Entry Type: select list  
Range Limits: (Yes, No)  
Default/Initialized value: **no**
- H tH t Horn**      Horn – High High Volume Set Point: Enables the audible annunciator for the High High Set Point if associated with one of the numbered set point LEDs.  
Entry Type: select list  
Range Limits: (Yes, No)  
Default/Initialized value: **YES**
- H tH Horn**      Horn – High Volume Set Point: Enables the audible annunciator for the High Set Point if associated with one of the numbered set point LEDs.  
Entry Type: select list  
Range Limits: (Yes, No)  
Default/Initialized value: **YES**
- Lo Horn**      Horn – Low Volume Set Point: Enables the audible annunciator for the Low Set Point if associated with one of the numbered set point LEDs.  
Entry Type: select list  
Range Limits: (Yes, No)  
Default/Initialized value: **YES**
- LoLo Horn**      Horn – Low Low Volume Set Point: Enables the audible annunciator for the Low Low Set Point if associated with one of the numbered set point LEDs.  
Entry Type: select list  
Range Limits: (Yes, No)  
Default/Initialized value: **no**
- Cr tLHorn**      Horn – Critical Low Volume Set Point: Enables the audible annunciator for the Critical Low Set Point if associated with one of the numbered set point LEDs.  
Entry Type: select list  
Range Limits: (Yes, No)  
Default/Initialized value: **no**

- tEnP H iH i**     Set Point – High High Temperature: This is one of the two programmable overage alarms for detecting a product temperature at or above the programmed threshold. It can also be used to control an integrated relay.  
Entry Type: 3 digit numeric, %  
Range Limits: 0-99.9%  
Default/Initialized value: **900**
- tEnP H i9h**     Set Point – High Temperature: This is one of the two programmable overage alarms for detecting a product temperature at or above the programmed threshold. It can also be used to control an integrated relay.  
Entry Type: 3 digit numeric, %  
Range Limits: 0-99.9%  
Default/Initialized value: **430**
- tEnP Lo**         Set Point – Low Temperature: This is one of the two programmable underage alarms for detecting a product temperature at or below the programmed threshold. It can also be used to control an integrated relay.  
Entry Type: 3 digit numeric, %  
Range Limits: 0-99.9%  
Default/Initialized value: **400**
- tEnP LoLo**     Set Point – Low Temperature: This is one of the two programmable underage alarms for detecting a product temperature at or below the programmed threshold. It can also be used to control an integrated relay.  
Entry Type: 3 digit numeric, %  
Range Limits: 0-99.9%  
Default/Initialized value: **250**
- HHtP Horn**     Horn – High High Temperature Set Point: Enables the audible annunciator for the High High Temperature Set Point.  
Entry Type: select list  
Range Limits: (Yes, No)  
Default/Initialized value: **YES**
- H i tP Horn**     Horn – High Temperature Set Point: Enables the audible annunciator for the High Temperature Set Point.  
Entry Type: select list  
Range Limits: (Yes, No)  
Default/Initialized value: **no**
- LotP Horn**     Horn – Low Temperature Set Point: Enables the audible annunciator for the Low Temperature Set Point.  
Entry Type: select list  
Range Limits: (Yes, No)  
Default/Initialized value: **no**
- LLtP Horn**     Horn – Low Low Temperature Set Point: Enables the audible annunciator for the Low Low Temperature Set Point.  
Entry Type: select list  
Range Limits: (Yes, No)  
Default/Initialized value: **YES**

- Tank Type**      Tank Type: There are five different tank types as outlined below. This entry allows the user to select one of those tank types.  
 Entry Type: Select List  
 Range Limits: N/A  
 Default/Initialized value: **FLAT**  
 Item List:    **FLAT** Flat-ended horizontal cylinder.  
                  **VERT** Vertical. Any tank with a constant volume/height.  
                  **CUS3** Custom 3. Typically used on fiberglass UST.  
                  **CUS8** Custom 8. Primarily used on asymmetrical tanks.  
                  **CONE** Cone. Vertical cylinders with a conical bottom.
- Tank CAP**      Tank Capacity: **Actual** tank capacity in gallons.  
 Entry Type: 6-digit numeric  
 Range Limits: 0 - 999,999  
 Default/Initialized value: **0**
- Manifold**      Manifold Factor: This entry is selected when multiple tanks of the same geometry are manifolded together and monitored with one probe located in the primary tank. The manifold factor reflects the number of tanks connected to the primary tank. If no tanks are manifolded together, the system should be set to (**none**).  
 Entry Type: select list  
 Range Limits: None, 1-6  
 Default/Initialized value: **none**
- Tank RAD**      Tank Radius: This entry requires the user to enter the **tank radius**. The radius is half of the diameter. Needed for tank types of FLAT, CUSTOM 3, and CONE.  
 Entry Type: 4 digit numeric  
 Range Limits: 0- 999.9  
 Default/Initialized value: **00**

**Entry 15E**

**Tank Rise:** This menu determines Tank Tilt. This entry requires the user to **manually Dip and record a field measured fuel height**. Applies to tank types of FLAT and CUSTOM 3.


**Note:** Tank tilt is calculated over the entire tank length.

Entry Type: 2-digit numeric  
 Range Limits: 0-9.9  
 Default/Initialized value: 00

**Calculating Tank Rise**

The user sticks and records fuel level in two of the riser openings that are the greatest distance apart. The fuel height difference is multiplied by the ratio set by dividing the total tank length (L1) by the distance between the two risers (L2).

See the following illustration and Example:



DRAWING NO. 20163 REV. N/C

**User Measured Values:**

Fuel Level in Riser #1 (H2) =30"  
 Fuel Level in Riser #2 (H3) =25"  
 Distance between the (2) risers (L2) = 200"  
 Total Tank Length (L1) = 300"

**User Calculations:**

Difference in fuel level between risers= 30" (H2) – 25" (H3) =5"  
 Calculated ratio between the Total Tank Length over the distance between the risers= 1.5

$$\frac{\text{Total Tank Length (L1)}}{\text{Distance between the risers (L2)}} = \frac{300''}{200''} = 1.5 \text{ Ratio}$$

The above value 1.5 is then multiplied by the difference in fuel level calculated between the risers. 1.5 x 5" = 7.5" Tank rise or tilt (H1) over the entire tank.

**Entry 16E**

**Tank Height:** This entry requires the user to enter **inside tank height**. Needed for tank type of VERTICAL, CUSTOM 8, and CONE.

Entry Type: 5-digit numeric  
 Range Limits: 0 - 1999.9  
 Default/Initialized value: 00

<b>tAnk LE</b>	<p><u>Tank Length:</u> This entry requires the user to enter <b>inside tank length</b> dimension. Needed for tank type of CUSTOM 3 if TANK RISE is not zero.          Entry Type: 5-digit numeric          Range Limits: 0.0 - 1999.9          Default/Initialized value: <b>00</b></p>
<b>ConE Ht</b>	<p><u>Cone Height:</u> Defines the height of the cone bottom.          Entry Type: 3-digit numeric          Range Limits: 0.0 - 99.9          Default/Initialized value: <b>00</b></p>
<b>HE ight</b>	<p><u>Height #:</u> This entry identifies the <b>inside liquid height</b> for which a matching volume is needed. This value will be based on the TANK RADIUS entered for a CUSTOM 3 tank type OR will be required to be manually entered for a CUSTOM 8 tank type.          Entry Type: 5-digit numeric          Range Limits: 0.0 - 9999.9          Default/Initialized value: <b>00</b></p>
<b>UOLUNE</b>	<p><u>Volume #:</u> This entry identifies the <b>inside liquid volume</b> for the HEIGHT defined immediately preceding this setting. This value should be based on either the tank manufacturer's calibration chart or on calculated values.          Entry Type: 6-digit numeric          Range Limits: 0 - 999999          Default/Initialized value: <b>0</b></p>
<b>thEft En</b>	<p><u>Theft Enable:</u> Activates theft monitoring when the following conditions are valid:          1. Station is closed for business, according to hours of operation programmed in THEFT submenu.          2. Withdrawal exceeds MINIMUM LOG VOLUME programmed in PROBE submenu.          Entry Type: select list          Range Limits: (Yes, No)          Default/Initialized value: <b>no</b></p>
<b>UnUSEAbLE</b>	<p><u>Unusable Volume:</u> Represents the product volume below a submersible or suction pump that cannot be utilized.          Entry Type: 6-digit numeric          Range Limits: 0 – 999999          Default/Initialized value: <b>0</b></p>
<b>UnGAUGEAbL</b>	<p><u>Ungaugeable Level:</u> Represents the minimum gaugeable level in the tank. This applies to probes which are mounted in a fixed position to a flange and or suspended from the top of a tank. One example where this setting would be used is in chemical mixing tanks where the internal construction would prevent the probe from being located near the bottom. At this level, the TMS will report and display a message showing a product level equal to the float as low as it can travel. The actual product level in the tank may be below the reported TMS value or empty. When the level drops to this point, the TMS will display a Low Product (<b>Low Prod</b>) message.          Entry Type: 5-digit numeric          Range Limits: 0.0 - 9999.9          Default/Initialized value: <b>00</b></p>
<b>rEturN</b>	<p><u>Return:</u>          *Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the CONFIG submenu showing TANK.           *Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the TANK menu showing TANK ENABLE.</p>

3.2.3 PROBE

**CONF**

<b>HEAdEr</b>	Header - Global System Settings
<b>tAnk</b>	Tank - Programming setup
<b>PrObE</b>	<b>Probe - Programming setup</b>
<b>rELY tAnk</b>	Relay Tank - Programming tank related alarms to control relays
<b>rELY cc</b>	Relay Contact Closure - Programming contact closure inputs to control relays
<b>rELY SEnS</b>	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
<b>rELY S tE</b>	Relay Site - Programming site related alarms/errors to control relays
<b>rELY ModE</b>	Relay Mode - Status of relay operation
<b>cc inPut</b>	Contact Closure Input
<b>SEnSr inP</b>	Sensor Input
<b>InuEntorY</b>	Tank Inventory Log Data setup
<b>tHEFt</b>	Theft - Detection (Hours of operation)
<b>ModEm</b>	Modem Communications - Setup
<b>d iAL out</b>	Auto-Dial out - Setup for selected Alarms or Tank information
<b>rEturN</b>	Return - Exits CONFIG menu

**PrObE**      Probe A collection of settings that are all probe-specific.

**PrObE tYP**      Probe Type: This value is located on the label at the head of the probe and is identified as the Model.  
 Entry Type: select list  
 Range Limits: N/A  
 Default/Initialized value: **MP550**  
 Item List:                      **MP550** MP550                      **---** Obsolete  
    **MP552** MP552                      **---** Obsolete                      **MP551** MP551  
    **MP561** MP561                      **MP562** MP562                      **MP563** MP563


**PrObE LEn**      Probe Length: This value is located on the label at the head of the probe.  
 Entry Type: 5-digit numeric  
 Range Limits: 0.0 - 1999.9  
 Default/Initialized value: **00**

**PrObE HO**      Product Float Height Offset: This is a level offset provided to compensate for other variables like float depth in the liquid and mounting height of the probe. This can only be performed if the float is buoyant in the product.  
 Entry Type: 4-digit numeric  
 Range Limits: +/- 0.0 - 299.9  
 Default/Initialized value: **-0000**



**Probe Loc**      Probe Location Offset: Represents the horizontal distance to the probe (L2) from the high end of the tank. This setting is used in conjunction with TANK RISE in the TANK sub menu.  
 Entry Type: 4-digit numeric  
 Range Limits: 0.0 - 599.9  
 Default/Initialized value: **0000**

**Probe Location Offset Illustration**



DRAWING NO. 20164 REV. N/C

**Not bAnd**      Motion Height Band: This entry allows the user to enter minimum fuel trip value for probe float travel. This entry will negate the possibility of wave action in the tank, which can trigger false transactions. The value represents the distance the float must travel within one minute to initiate transaction monitoring. The transaction is considered complete when the motion height band is NOT exceeded for three consecutive minutes.  
 Entry Type: 2-digit numeric  
 Range Limits: 0.00 - 0.99"  
 Default/Initialized value: **0.20**

**Lo9 n in**      Minimum Logged Volume: Represents the minimum volume change of a transaction that will be recorded in the appropriate log. Any transactions that do NOT meet this minimum are discarded.  
 Entry Type: 3-digit numeric  
 Range Limits: 0 - 999/g  
 Default/Initialized value: **50**

**rEt urn**      Return  
 \*Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the CONFIG submenu showing PROBE.  
  
 \*Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the PROBE menu showing PROBE TYPE.

3.2.4 RELAY TANK

CONF 19

<b>HEAdEr</b>	Header - Global System Settings
<b>tRAnk</b>	Tank - Programming setup
<b>PrObE</b>	Probe - Programming setup
<b>rELY tRAnk</b>	<b>Relay Tank - Programming tank related alarms to control relays</b>
<b>rELY cc</b>	Relay Contact Closure - Programming contact closure inputs to control relays
<b>rELY SEnS</b>	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
<b>rELY S tE</b>	Relay Site - Programming site related alarms/errors to control relays
<b>rELY ModE</b>	Relay Mode - Status of relay operation
<b>cc inPut</b>	Contact Closure Input
<b>SEnSr inP</b>	Sensor Input
<b>InuEntorY</b>	Tank Inventory Log Data setup
<b>tHEFT</b>	Theft - Detection (Hours of operation)
<b>ModEm</b>	Modem Communications - Setup
<b>d iAL out</b>	Auto-Dial out - Setup for selected Alarms or Tank information
<b>rEturN</b>	Return - Exits CONFIG menu

**rELY tRAnk** Relay Tank: A list of conditions monitored by the level probe that can each affect up to three relays. The Default/Initialized value for all settings is **noNoNo**. Each NO represents a potential relay position that is disabled. It is enabled by changing NO to the number of the relay to be activated.

This setting can be edited if editing has been enabled via DIP switch 1. Once enabled, pressing the EDIT (TEST) button will cause the display to flash. Even though the entire display is flashing, only the first position is currently selected. Using the ▲ and ▼ buttons will cycle through the choices at the first position. Pressing ► will advance to the next position but the display will NOT change. Repeating this process will allow all three positions to be edited.

- Crth tR 19** Relay Trigger – Critical High Product: List of relays to be triggered by the Critical High Product Set Point  
Entry Type: numeric list  
Range Limits: (01-04).(01-04).(01-04)  
Default/Initialized value: **noNoNo**
- H iH i tR 19** Relay Trigger – High High Product: List of relays to be triggered by the High High Product Set Point  
Entry Type: numeric list  
Range Limits: (01-04).(01-04).(01-04)  
Default/Initialized value: **noNoNo**
- H iH tR 19** Relay Trigger – High Product: List of relays to be triggered by the High Product Set Point  
Entry Type: numeric list  
Range Limits: (01-04).(01-04).(01-04)  
Default/Initialized value: **noNoNo**
- Lo tR 19** Relay Trigger – Low Product: List of relays to be triggered by the Low Product Set Point  
Entry Type: numeric list  
Range Limits: (01-04).(01-04).(01-04)  
Default/Initialized value: **noNoNo**
- LoLo tR 19** Relay Trigger – Low Low Product: List of relays to be triggered by the Low Low Product Set Point  
Entry Type: numeric list  
Range Limits: (01-04).(01-04).(01-04)  
Default/Initialized value: **noNoNo**

- CrLl tr 9**      Relay Trigger – Critical Low Product: List of relays to be triggered by the Critical Low Product Set Point  
Entry Type: numeric list  
Range Limits: (01-04).(01-04).(01-04)  
Default/Initialized value: **nnnnnn**
- HHtP tr 9**      Relay Trigger – High High Product Temperature: List of relays to be triggered by the High High Product Temperature Set Point  
Entry Type: numeric list  
Range Limits: (01-04).(01-04).(01-04)  
Default/Initialized value: **nnnnnn**
- HtP tr 9**      Relay Trigger – High Product Temperature: List of relays to be triggered by the High Product Temperature Set Point  
Entry Type: numeric list  
Range Limits: (01-04).(01-04).(01-04)  
Default/Initialized value: **nnnnnn**
- LoLp tr 9**      Relay Trigger – Low Product Temperature: List of relays to be triggered by the Low Product Temperature Set Point  
Entry Type: numeric list  
Range Limits: (01-04).(01-04).(01-04)  
Default/Initialized value: **nnnnnn**
- LLtP tr 9**      Relay Trigger – Low Low Product: List of relays to be triggered by the Low Low Product Temperature Set Point  
Entry Type: numeric list  
Range Limits: (01-04).(01-04).(01-04)  
Default/Initialized value: **nnnnnn**
- rEturN**      Return  
\*Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the CONFIG submenu showing RELAY TANK.  
  
\*Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the RELAY TANK menu showing CRITICAL HIGH TRIGGER.

**3.2.5 RELAY CONTACT CLOSURE**

**CONF 19**

<b>HEAdEr</b>	Header - Global System Settings
<b>tAnk</b>	Tank - Programming setup
<b>PrObE</b>	Probe - Programming setup
<b>rELY tAnk</b>	Relay Tank - Programming tank related alarms to control relays
<b>rELY cc</b>	<b>Relay CC - Programming contact closure inputs to control relays</b>
<b>rELY SEnS</b>	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
<b>rELY S tE</b>	Relay Site - Programming site related alarms/errors to control relays
<b>rELY ModE</b>	Relay Mode - Status of relay operation
<b>cc inPut</b>	Contact Closure Input
<b>SEnSr inP</b>	Sensor Input
<b>InuEntorY</b>	Tank Inventory Log Data setup
<b>tHEFt</b>	Theft - Detection (Hours of operation)
<b>ModEr</b>	Modem Communications - Setup
<b>d iAL out</b>	Auto-Dial out - Setup for selected Alarms or Tank information
<b>rEturN</b>	Return - Exits CONFIG menu

**rELY cc**     Relay – Contact Closure: A non-hazardous contact closure (CC) input can affect up to three relays. The Default/Initialized value for all settings is **noNoNo**. Each NO represents a potential relay position that is disabled. It is enabled by changing NO to the number of the relay to be activated. The number at the left of the display represents the CC input number.

This setting can be edited if editing has been enabled via DIP switch 1. Once enabled, pressing the EDIT (TEST) button will cause the display to flash. Even though the entire display is flashing, only the first position is currently selected. Using the ▲ and ▼ buttons will cycle through the choices at the first position. Pressing ► will advance to the next position but the display will NOT change. Repeating this process will allow all three positions to be edited.

**cc tr 19**     Contact Closure Trigger: List of relays to be triggered by a non-hazardous Contact Closure (CC) Input. The number at the left of the display represents the CC input number.  
 Entry Type: numeric list  
 Range Limits: (01-04).(01-04).(01-04)  
 Default/Initialized value: **noNoNo**

**rEturN**     Return  
 \*Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the CONFIG submenu showing RELAY CC.

\*Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the RELAY CC menu showing CONTACT CLOSURE TRIGGER.

**3.2.6 RELAY SENSOR**

**CONF IG**

<b>HEAdEr</b>	Header - Global System Settings
<b>tAnk</b>	Tank - Programming setup
<b>PrObE</b>	Probe - Programming setup
<b>rELY tAnk</b>	Relay Tank - Programming tank related alarms to control relays
<b>rELY cC</b>	Relay Contact Closure - Programming contact closure inputs to control relays
<b>rELY SEnS</b>	<b>Relay Sensor - Using Intrinsically Safe sensor inputs to control relays</b>
<b>rELY S itE</b>	Relay Site - Programming site related alarms/errors to control relays
<b>rELY ModE</b>	Relay Mode - Status of relay operation
<b>cC inPut</b>	Contact Closure Input
<b>SEnSr inP</b>	Sensor Input
<b>InuEntorY</b>	Tank Inventory Log Data setup
<b>tHEFT</b>	Theft - Detection (Hours of operation)
<b>ModEm</b>	Modem Communications - Setup
<b>d iAL out</b>	Auto-Dial out - Setup for selected Alarms or Tank information
<b>rEturN</b>	Return - Exits CONFIG menu

**rELY SEnS**     Relay – Sensor: A Sensor input can affect up to three relays. The Default/Initialized value for all settings is **nanano**. Each NO represents a potential relay position that is disabled. It is enabled by changing NO to the number of the relay to be activated. The number at the left of the display represents the Sensor input number.

This setting can be edited if editing has been enabled via DIP switch 1. Once enabled, pressing the EDIT (TEST) button will cause the display to flash. Even though the entire display is flashing, only the first position is currently selected. Using the ▲ and ▼ buttons will cycle through the choices at the first position. Pressing ► will advance to the next position but the display will NOT change. Repeating this process will allow all three positions to be edited.

**SEnS tr IG**     Sensor Trigger: List of relays to be triggered by a Sensor Input. The number at the left of the display represents the Sensor input number.  
 Entry Type: numeric list  
 Range Limits: (01-04).(01-04).(01-04)  
 Default/Initialized value: **nanano**

**rEturN**     Return  
 \*Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the CONFIG submenu showing RELAY SENSOR.

\*Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the RELAY SENSOR menu showing SENSOR TRIGGER.

**3.2.7 RELAY SITE**

**CONF**

<b>HEAdEr</b>	Header - Global System Settings
<b>tAnk</b>	Tank - Programming setup
<b>PrObE</b>	Probe - Programming setup
<b>rELY tAnk</b>	Relay Tank - Programming tank related alarms to control relays
<b>rELY cc</b>	Relay Contact Closure - Programming contact closure inputs to control relays
<b>rELY SEnS</b>	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
<b>rELY S tE</b>	<b>Relay Site - Programming site related alarms/errors to control relays</b>
<b>rELY ModE</b>	Relay Mode - Status of relay operation
<b>cc inPut</b>	Contact Closure Input
<b>SEnSr inP</b>	Sensor Input
<b>InuEntorY</b>	Tank Inventory Log Data setup
<b>tHEFT</b>	Theft - Detection (Hours of operation)
<b>ModEm</b>	Modem Communications - Setup
<b>d iAL out</b>	Auto-Dial out - Setup for selected Alarms or Tank information
<b>rEturN</b>	Return - Exits CONFIG menu

**rELY S tE** Relay – Site Specific: A Site Specific condition can affect up to three relays. The Default/Initialized value for all settings is **nooooo**. Each NO represents a potential relay position that is disabled. It is enabled by changing NO to the number of the relay to be activated. The number at the left of the display represents the Sensor input number.

This setting can be edited if editing has been enabled via DIP switch 1. Once enabled, pressing the EDIT (TEST) button will cause the display to flash. Even though the entire display is flashing, only the first position is currently selected. Using the ▲ and ▼ buttons will cycle through the choices at the first position. Pressing ► will advance to the next position but the display will NOT change. Repeating this process will allow all three positions to be edited.

**tHEFT** Theft Trigger: List of relays to be triggered by a Theft of Product.  
 Entry Type: numeric list  
 Range Limits: (01-04).(01-04).(01-04)  
 Default/Initialized value: **nooooo**

**PowerFR iL** Power Fail Trigger: List of relays to be triggered by the Power Fail, Warning 21 message  
 Entry Type: numeric list  
 Range Limits: (01-04).(01-04).(01-04)  
 Default/Initialized value: **nooooo**

**SYS Error** System Error Trigger: List of relays to be triggered by any System Error/Event.  
 Entry Type: numeric list  
 Range Limits: (01-04).(01-04).(01-04)  
 Default/Initialized value: **nooooo**

**rEturN** Return  
 \*Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the CONFIG submenu showing RELAY SITE.

\*Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the RELAY SITE menu showing THEFT.

### 3.2.8 RELAY MODE

#### CONF 19

<b>HEAdEr</b>	Header - Global System Settings
<b>tAnk</b>	Tank - Programming setup
<b>PrObE</b>	Probe - Programming setup
<b>rELY tAnk</b>	Relay Tank - Programming tank related alarms to control relays
<b>rELY cC</b>	Relay Contact Closure - Programming contact closure inputs to control relays
<b>rELY SEnS</b>	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
<b>rELY S itE</b>	Relay Site - Programming site related alarms/errors to control relays
<b>rELY ModE</b>	<b>Relay Mode - Status of relay operation</b>
<b>cC inPut</b>	Contact Closure Input
<b>SEnSr inP</b>	Sensor Input
<b>InuEntorY</b>	Tank Inventory Log Data setup
<b>tHEFT</b>	Theft - Detection (Hours of operation)
<b>ModEm</b>	Modem Communications - Setup
<b>d iAL out</b>	Auto-Dial out - Setup for selected Alarms or Tank information
<b>rEturN</b>	Return - Exits CONFIG menu

**rELY ModE**     Relay Mode/Behavior: This menu contains various settings to control the behavior of a relay. The number at the left of the display represents the relay output number.

**NOrnALLY**     Normal Contact State (Normally): Defines the default power state of a relay output as either Powered Off or Powered On. The Powered On selection provides a Failsafe relay output since all relays are Powered Off when the TMS loses power.  
Entry Type: select list  
Range Limits: (On, Off)  
Default/Initialized value: **OFF**

**FP Act**     Front Panel Acknowledgment (FP Ack): When enabled, returns the state of the programmed relay to its normal state as defined in NORMALLY.  
Entry Type: select list  
Range Limits: (Yes, No)  
Default/Initialized value: **no**

**dELAY**     Delay: Provides a time delay to automatically return a relay to its normal state. This feature is disabled by selecting NONE.  
Entry Type: select list in minutes  
Range Limits: (None, 1-9)  
Default/Initialized value: **nonE**

**LAtch En**     Latch Enable: Offers the ability for a relay to be manipulated by a secondary condition to return the relay to the normal state. When activated, all references to this particular relay in other menus would represent the Latch On condition(s). Any of the settings below define the Latch Off condition for this relay.  
Entry Type: select list  
Range Limits: (Yes, No)  
Default/Initialized value: **no**  
Example: A common pump control scenario would have a relay activate on a Low Set Point and deactivate on a High Set Point. This would allow the tank to be filled before deactivating the pump. Note: Pumps are NOT controlled directly by the TMS. The TMS would simply provide a signal to represent when the pump should run.

- Cr tH OFF**      Latch Off – Critical High Product: When selected, returns the relay to normal when tank reaches the Critical High Set Point.  
Entry Type: select list  
Range Limits: N/A  
Default/Initialized value: **tnt no**  
Item List:            **tnt no** = Feature disabled (no tank selected)  
                         **tnt I** = Feature enabled
- H tH t OFF**      Latch Off – High High Product: When selected, returns the relay to normal when tank reaches the High High Set Point.  
Entry Type: select list  
Range Limits: N/A  
Default/Initialized value: **tnt no**  
Item List:            **tnt no** = Feature disabled (no tank selected)  
                         **tnt I** = Feature enabled
- H tH OFF**        Latch Off – High Product: When selected, returns the relay to normal when tank reaches the High Set Point.  
Entry Type: select list  
Range Limits: N/A  
Default/Initialized value: **tnt no**  
Item List:            **tnt no** = Feature disabled (no tank selected)  
                         **tnt I** = Feature enabled
- Lo OFF**          Latch Off – Low Product: When selected, returns the relay to normal when tank reaches the Low Set Point.  
Entry Type: select list  
Range Limits: N/A  
Default/Initialized value: **tnt no**  
Item List:            **tnt no** = Feature disabled (no tank selected)  
                         **tnt I** = Feature enabled
- LoLo OFF**        Latch Off – Low Low Product: When selected, returns the relay to normal when tank reaches the Low Low Set Point.  
Entry Type: select list  
Range Limits: N/A  
Default/Initialized value: **tnt no**  
Item List:            **tnt no** = Feature disabled (no tank selected)  
                         **tnt I** = Feature enabled
- Cr tL OFF**        Latch Off – Critical Low Product: When selected, returns the relay to normal when tank reaches the Critical Low Set Point.  
Entry Type: select list  
Range Limits: N/A  
Default/Initialized value: **tnt no**  
Item List:            **tnt no** = Feature disabled (no tank selected)  
                         **tnt I** = Feature enabled
- SEnSr OFF**      Latch Off – Sensor: When selected, returns the relay to normal when tank reaches the selected Sensor.  
Entry Type: select list  
Range Limits: N/A  
Default/Initialized value: **lnP no**  
Item List:            **lnP no** = Feature disabled (no tank selected)  
                         **lnP 1** = Latch Off for sensor 1 activity  
                         **lnP 2** = Latch Off for sensor 2 activity



- HHLP OFF**      Latch Off – High High Product Temperature: When selected, returns the relay to normal when tank reaches the High High Temperature Set Point.  
 Entry Type: select list  
 Range Limits: N/A  
 Default/Initialized value: **lnt no**  
 Item List:        **lnt no** = Feature disabled (no tank selected)  
                       **lnt I** = Feature enabled
- HLTP OFF**      Latch Off – High Product Temperature: When selected, returns the relay to normal when tank reaches the High Temperature Set Point.  
 Entry Type: select list  
 Range Limits: N/A  
 Default/Initialized value: **lnt no**  
 Item List:        **lnt no** = Feature disabled (no tank selected)  
                       **lnt I** = Feature enabled
- LoTP OFF**      Latch Off – Low Product Temperature: When selected, returns the relay to normal when tank reaches the Low Temperature Set Point.  
 Entry Type: select list  
 Range Limits: N/A  
 Default/Initialized value: **lnt no**  
 Item List:        **lnt no** = Feature disabled (no tank selected)  
                       **lnt I** = Feature enabled
- LLLP OFF**      Latch Off – Low Low Product Temperature: When selected, returns the relay to normal when tank reaches the Low Low Temperature Set Point.  
 Entry Type: select list  
 Range Limits: N/A  
 Default/Initialized value: **lnt no**  
 Item List:        **lnt no** = Feature disabled (no tank selected)  
                       **lnt I** = Feature enabled
- rEturn**            Return  
 \*Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the CONFIG submenu showing RELAY MODE.  
  
 \*Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the RELAY MODE menu showing NORMALLY.

3.2.9 CONTACT CLOSURE INPUT

CONF 19

<b>HEAdEr</b>	Header - Global System Settings
<b>tAnk</b>	Tank - Programming setup
<b>PrObE</b>	Probe - Programming setup
<b>rELY tAnk</b>	Relay Tank - Programming tank related alarms to control relays
<b>rELY cc</b>	Relay Contact Closure - Programming contact closure inputs to control relays
<b>rELY SEnS</b>	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
<b>rELY S tE</b>	Relay Site - Programming site related alarms/errors to control relays
<b>rELY ModE</b>	Relay Mode - Status of relay operation
<b>cc inP</b>	<b>Contact Closure Input</b>
<b>SEnSr inP</b>	Sensor Input
<b>InuEntorY</b>	Tank Inventory Log Data setup
<b>tHEFt</b>	Theft - Detection (Hours of operation)
<b>ModEn</b>	Modem Communications - Setup
<b>dIAL out</b>	Auto-Dial out - Setup for selected Alarms or Tank information
<b>rEturN</b>	Return - Exits CONFIG menu

**cc inP**      Contact Closure Input This entry allows the user to configure and enable each external contact closure input for Relay, Alarm, Acknowledgment, and Gate function control. The number at the left of the display represents the CC input number.

**Example:** Any contact closure input can be programmed as a **Gate** function to add an extra condition to any relay output, such as disabling a pump override control application. Similarly, the user may select to **Acknowledge** any contact closure input, such as a remote mounted Horn or Beacon, disabling the optional relay contact(s) that have been programmed to trigger the remotely located annunciating alarm device.

**cc EnAbLE**      Contact Closure (CC) Enable: User enters choice of dry contact closure input. Options include Off, Relay, Gate Control function, Alarm or Acknowledge. The contact closure selection entered will enable and operate in one of the above modes. User will select from menu for specific contact closure operational modes.  
 Entry Type: Select list  
 Range Limits: N/A  
 Default/Initialized value: **OFF**  
 Item List: **OFF** Off: Input is disabled  
**rELAY** Relay: Input intended to control one or more relay outputs  
**gAtE** Gate: Input becomes part of an AND logic gate defined by other conditions that reference the same relay output  
**ALArM** Alarm: Input intended to receive an alarm signal.  
**AcK** Acknowledge: Input will acknowledge or return to the normal state all defined relays.  
**FPAcK** Front Panel Acknowledge: Input will acknowledge the front panel horn. This is intended for use with PLC/BMS systems.

**inP nAmE**      Input Name: Selects a name for the input. Visible only through TMS Communicator or in the Alarm Log.  
 Entry Type: select list  
 Range Limits: None  
 Default/Initialized value: **USEr**  
 Item List:

<b>USEr</b> User-defined	<b>gEnEr</b> Generator
<b>rES 1</b> Reserve 1	<b>rES 2</b> Reserve 2
<b>rES 4</b> Reserve 4	<b>rES 3</b> Reserve 3
<b>L2PASS</b> Line 2 Pass	<b>L1FA iL</b> Line 1 Fail
<b>L3FA iL</b> Line 3 Fail	<b>L3PASS</b> Line 3 Pass
<b>PunP</b> Pump	<b>L4PASS</b> Line 4 Pass
	<b>L4FA iL</b> Line 4 Fail

<b>USER NAME</b>	<p><u>User Name</u>: A six character custom name assigned using TMS Communicator.          Entry Type: 6 character, alphanumeric          Range Limits: None          Default/Initialized value: <b>INPUT</b></p>
<b>NORMALLY</b>	<p><u>Normal Contact State (Normally)</u>: Defines the input's normal or non-action state as either open or closed.          Entry Type: select list          Range Limits: (Open, Close)          Default/Initialized value: <b>CLOSE</b></p>
<b>LOGIC EN</b>	<p><u>Logic Enable Group</u>: Selects the input to become a member of an AND logic group identified by its letter. All inputs within the lettered logic group must be active before any assigned relays will activate.          Entry Type: select list          Range Limits: AND (A-H)          Default/Initialized value: <b>OFF</b></p>
<b>TIMEDELAY</b>	<p><u>Time Delay</u>: When an input is part of a lettered logic group, this feature can apply a time delay, either going active or inactive, before considering the input to be truly active/inactive. After the time delay passes, the logic rules are applied.          Entry Type: select list          Range Limits: N/A          Default/Initialized value: <b>00 SEC</b>          Item List:  <b>00 SEC</b> Disabled. CC Input reported realtime  <b>02 SEC</b> 2 second delay before CC Input is reported active  <b>05 SEC</b> 5 second delay before CC Input is reported active  <b>10 SEC</b> 10 second delay before CC Input is reported active  <b>20 SEC</b> 20 second delay before CC Input is reported active  <b>02 SEC</b> 2 second delay before CC Input is reported inactive  <b>05 SEC</b> 5 second delay before CC Input is reported inactive  <b>10 SEC</b> 10 second delay before CC Input is reported inactive  <b>20 SEC</b> 20 second delay before CC Input is reported inactive</p>
<b>RETURN</b>	<p><u>Return</u>          *Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the CONFIG submenu showing CC INPUT.           *Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the CC INPUT menu showing CC ENABLE.</p>



<b>USER NAME</b>	<p><u>User Name</u>: A six character custom name assigned using TMS Communicator. Entry Type: 6 character, alphanumeric Range Limits: None Default/Initialized value: <b>INPUT</b></p>
<b>FAULT EN</b>	<p><u>Fault Enable</u>: In supervised mode the system will detect and report short-circuited and open-circuited sensor field wiring when used in conjunction with fault reporting sensors. Fault-reporting leak sensors will require the Pneumercator type "FL" series or compatible. Select YES to enable the fault detection. Entry Type: select list Range Limits: (Yes, No) Default/Initialized value: <b>no</b></p>
<b>NORMALLY</b>	<p><u>Normal Contact State (Normally)</u>: Defines the input's normal or non-action state as either open or closed. Entry Type: select list Range Limits: (Open, Close) Default/Initialized value: <b>CLOSE</b></p>
<b>RETURN</b>	<p><u>Return</u> *Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the CONFIG submenu showing SENSOR INPUT.  *Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the SENSOR INPUT menu showing SENSOR ENABLE.</p>

3.2.11 INVENTORY

CONF 19

<b>HEAdEr</b>	Header - Global System Settings
<b>tAnk</b>	Tank - Programming setup
<b>PrObE</b>	Probe - Programming setup
<b>rELY tAnk</b>	Relay Tank - Programming tank related alarms to control relays
<b>rELY cc</b>	Relay Contact Closure - Programming contact closure inputs to control relays
<b>rELY SEnS</b>	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
<b>rELY S tE</b>	Relay Site - Programming site related alarms/errors to control relays
<b>rELY ModE</b>	Relay Mode - Status of relay operation
<b>cc inPut</b>	Contact Closure Input
<b>SEnSr inP</b>	Sensor Input
<b>InuEntorY</b>	<b>Tank Inventory Log Data setup</b>
<b>tHEft</b>	Theft - Detection (Hours of operation)
<b>ModEm</b>	Modem Communications - Setup
<b>d iAL out</b>	Auto-Dial out - Setup for selected Alarms or Tank information
<b>rEturN</b>	Return - Exits CONFIG menu

**InuEntorY**     Inventory Log Setup: This menu allows the user to enable and program the **inventory** data reporting times for each tank, at up to three user-programmable times per day, selectable for each day of the week. The TMS will record an inventory snapshot at each **different** time programmed for each selected day of the week. The system will have the capacity to store up to the 6 most recent inventory records.

**Hour 1**     Hour 1: User enters which hour of the day in 24-hour format for the TMS to record inventory data snapshot in the Inventory Log.  
 Entry Type: 4-digit numeric hours, minutes  
 Range Limits: 00'00 – 23'59  
 Default/Initialized value: **00' 00**

**Hour 2**     Hour 2: User enters which hour of the day in 24-hour format for the TMS to record inventory data snapshot in the Inventory Log.  
 Entry Type: 4-digit numeric hours, minutes  
 Range Limits: 00'00 – 23'59  
 Default/Initialized value: **00' 00**

**Hour 3**     Hour 3: User enters which hour of the day in 24-hour format for the TMS to record inventory data snapshot in the Inventory Log.  
 Entry Type: 4-digit numeric hours, minutes  
 Range Limits: 00'00 – 23'59  
 Default/Initialized value: **00' 00**

**Sun EnAbL**     Sunday: The TMS will record an inventory snapshot in the Inventory Log on Sunday at each different time programmed above..  
 Entry Type: select list  
 Range Limits: (Yes, No)  
 Default/Initialized value: **no**

**Mon EnAbL**     Monday: The TMS will record an inventory snapshot in the Inventory Log on Monday at each different time programmed above..  
 Entry Type: select list  
 Range Limits: (Yes, No)  
 Default/Initialized value: **no**

**tue EnAbL**     Tuesday: The TMS will record an inventory snapshot in the Inventory Log on Tuesday at each different time programmed above..  
 Entry Type: select list  
 Range Limits: (Yes, No)  
 Default/Initialized value: **no**

- UEd EnAbl***      Wednesday: The TMS will record an inventory snapshot in the Inventory Log on Wednesday at each different time programmed above..  
Entry Type: select list  
Range Limits: (Yes, No)  
Default/Initialized value: **no**
- Thu EnAbl***      Thursday: The TMS will record an inventory snapshot in the Inventory Log on Thursday at each different time programmed above..  
Entry Type: select list  
Range Limits: (Yes, No)  
Default/Initialized value: **no**
- Fr i EnAbl***      Friday: The TMS will record an inventory snapshot in the Inventory Log on Friday at each different time programmed above..  
Entry Type: select list  
Range Limits: (Yes, No)  
Default/Initialized value: **no**
- SAt EnAbl***      Saturday: The TMS will record an inventory snapshot in the Inventory Log on Saturday at each different time programmed above..  
Entry Type: select list  
Range Limits: (Yes, No)  
Default/Initialized value: **no**
- rEturN***      Return  
\*Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the CONFIG submenu showing INVENTORY.  
  
\*Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the INVENTORY menu showing HOUR 1.

3.2.12 THEFT

CONF 19

<b>HEAdEr</b>	Header - Global System Settings
<b>tAnk</b>	Tank - Programming setup
<b>PrObE</b>	Probe - Programming setup
<b>rELY tAnk</b>	Relay Tank - Programming tank related alarms to control relays
<b>rELY cc</b>	Relay Contact Closure - Programming contact closure inputs to control relays
<b>rELY SEnS</b>	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
<b>rELY S itE</b>	Relay Site - Programming site related alarms/errors to control relays
<b>rELY ModE</b>	Relay Mode - Status of relay operation
<b>cc inPut</b>	Contact Closure Input
<b>SEnSr inP</b>	Sensor Input
<b>InuEntorY</b>	Tank Inventory Log Data setup
<b>tHEFT</b>	<b>Theft - Detection (Hours of operation)</b>
<b>ModEm</b>	Modem Communications - Setup
<b>d iAL out</b>	Auto-Dial out - Setup for selected Alarms or Tank information
<b>rEturN</b>	Return - Exits CONFIG menu

**tHEFT**      Theft: This menu allows the user to enable the system to detect and log and inventory decrease as a theft when the following conditions are valid:

1. Station is closed for business, according to hours of operation programmed in THEFT DETECT submenu.
2. Withdrawal exceeds MINIMUM LOG VOLUME programmed in TANK submenu for that tank.

The system will have the capacity to store up to the (2) most recent theft records.

**M-F OPEN**      Monday-Friday Open: User enters the hour of the day in 24-hour format for Monday-Friday that the facility **OPENS** for business and the tanks are available.  
 Entry Type: 4-digit numeric hours, minutes  
 Range Limits: 00'00 – 23'59  
 Default/Initialized value: **00' 00**

**M-F CLOSE**      Monday-Friday Close: User enters the hour of the day in 24-hour format for Monday-Friday that the facility **CLOSES** for business and the tanks are not available.  
 Entry Type: 4-digit numeric hours, minutes  
 Range Limits: 00'00 – 23'59  
 Default/Initialized value: **00' 00**

**SAt OPEN**      Saturday Open: User enters the hour of the day in 24-hour format for Saturday that the facility **OPENS** for business and the tanks are available.  
 Entry Type: 4 digit numeric hours, minutes  
 Range Limits: 00'00 – 23'59  
 Default/Initialized value: **00' 00**

**SAt CLOSE**      Saturday Close: User enters the hour of the day in 24-hour format for Saturday that the facility **CLOSES** for business and the tanks are not available.  
 Entry Type: 4-digit numeric hours, minutes  
 Range Limits: 00'00 – 23'59  
 Default/Initialized value: **00' 00**



- Sun OPEN**      Sunday Open: User enters the hour of the day in 24-hour format for Sunday that the facility **OPENS** for business and the tanks are available.  
Entry Type: 4 digit numeric hours, minutes  
Range Limits: 00'00 – 23'59  
Default/Initialized value: **00' 00**
- Sun CLOSE**      Sunday Close: User enters the hour of the day in 24-hour format for Sunday that the facility **CLOSES** for business and the tanks are not available.  
Entry Type: 4 digit numeric hours, minutes  
Range Limits: 00'00 – 23'59  
Default/Initialized value: **00' 00**
- rEturN**      Return  
\*Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the CONFIG submenu showing THEFT.  
  
\*Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the THEFT menu showing M-F OPEN.

3.2.13 MODEM

**CONF**

<b>HEAdEr</b>	Header - Global System Settings
<b>tAnk</b>	Tank - Programming setup
<b>PrObE</b>	Probe - Programming setup
<b>rELY tAnk</b>	Relay Tank - Programming tank related alarms to control relays
<b>rELY cc</b>	Relay Contact Closure - Programming contact closure inputs to control relays
<b>rELY SEnS</b>	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
<b>rELY S tE</b>	Relay Site - Programming site related alarms/errors to control relays
<b>rELY ModE</b>	Relay Mode - Status of relay operation
<b>cc inPut</b>	Contact Closure Input
<b>SEnSr inP</b>	Sensor Input
<b>InuEntorY</b>	Tank Inventory Log Data setup
<b>tHEft</b>	Theft - Detection (Hours of operation)
<b>ModEn</b>	<b>Modem Communications - Setup</b>
<b>dIAL out</b>	Auto-Dial out - Setup for selected Alarms or Tank information
<b>rEturn</b>	Return - Exits CONFIG menu

**ModEn**      Modem: Allows the user to enable and configure the secure internal modem system within the TMS locking enclosure to assure a positive telephone link; free of tampering.

**ModEn**      Modem Selection: Select which type of modem is installed in the TMS.  
 Entry Type: select list  
 Range Limits: N/A  
 Default/Initialized value: **nonE**  
 Item List:    **nonE** = No modem installed                      **intErnAL** = Internal modem  
                  **-----** = Not available                              **Port Mod** = External serial port modem

**baud rAtE**      Baud Rate: Defines the maximum baud rate allowed for the installed TMS modem.  
 Entry Type: Select list  
 Range Limits: 1.2K-14.4K (1,200 - 14,400)  
 Default/Initialized value: **240**  
 Item List:    **240** 2400 Baud                      **120** 1200 Baud                      **480** 4800 Baud  
                  **960** 9600 Baud                      **1440** 14,400 Baud

**dIAL tYPE**      Dial Type: Selects the capabilities of the telephone service as touch-tone or rotary pulse.  
 Entry Type: Select list  
 Range Limits: (Tone, Pulse)  
 Default/Initialized value: **tonE**

**PAUSE**          Pause: Defines the pause length of a comma within the dial-out phone number.  
 Entry Type: 1-digit numeric, seconds  
 Range Limits: 1-9  
 Default/Initialized value: **1 SEc**

**tEL L iNE**        Telephone Line: Defines the availability of the telephone line as dedicated for the TMS or shared with other equipment.  
 Entry Type: Select list  
 Range Limits: (Dedicated, Shared)  
 Default/Initialized value: **dEd icAtEd**

**rEturn**          Return  
 \*Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the CONFIG submenu showing MODEM.  
  
 \*Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the MODEM menu showing MODEM.

## 3.2.14 DIAL-OUT

**CONF 19**

<b>HEAdEr</b>	Header - Global System Settings
<b>tAnk</b>	Tank - Programming setup
<b>PrObE</b>	Probe - Programming setup
<b>rELY tAnk</b>	Relay Tank - Programming tank related alarms to control relays
<b>rELY cc</b>	Relay Contact Closure - Programming contact closure inputs to control relays
<b>rELY SEnS</b>	Relay Sensor - Using Intrinsically Safe sensor inputs to control relays
<b>rELY S itE</b>	Relay Site - Programming site related alarms/errors to control relays
<b>rELY ModE</b>	Relay Mode - Status of relay operation
<b>cc inPut</b>	Contact Closure Input
<b>SEnSr inP</b>	Sensor Input
<b>InuEntorY</b>	Tank Inventory Log Data setup
<b>tHEFT</b>	Theft - Detection (Hours of operation)
<b>ModEr</b>	Modem Communications - Setup
<b>d iAL out</b>	<b>Auto-Dial out - Setup for selected Alarms or Tank information</b>
<b>rEturN</b>	Return - Exits CONFIG menu

**d iAL out** Dial-out: Configures the phone number and conditions that initiate the TMS dial-out to a computer or other data device. The number at the left of the display represents the one of the five available dial-out configuration slots.

**tEL LOCAL** Telephone Number – Local: The TMS can support up to 21 digits in the dial-out phone number. This setting represents the rightmost seven digits of the 21 digits. This would be used for a local U.S. telephone number.  
Entry Type: up to 7 digits  
Range Limits: Per character: 0-9, P for Pause or comma, \_ for unneeded digit  
Default/Initialized value: -----

**tEL ArER** Telephone Number – Area Code: The TMS can support up to 21 digits in the dial-out phone number. This setting represents the centermost seven digits of the 21 digits. This could be used for the area code of a U.S. telephone number or for any digits needed beyond or to the left of the base or local seven digits.  
Entry Type: up to 7 digits  
Range Limits: Per character: 0-9, P for Pause or comma, \_ for unneeded digit  
Default/Initialized value: -----

**tEL ArER2** Telephone Number – Area Code 2: The TMS can support up to 21 digits in the dial-out phone number. This setting represents the leftmost seven digits of the 21 digits. This could be used for any digits needed beyond or to the left of the rightmost 14 digits.  
Entry Type: up to 7 digits  
Range Limits: Per character: 0-9, P for Pause or comma, \_ for unneeded digit  
Default/Initialized value: -----

**L inE tYPE** Receiving Device Type (Line Type): User can select the type of device that is being called by the TMS.  
Entry Type: Select list  
Range Limits: N/A  
Default/Initialized value: **dAtA**  
Item List:  
**dAtA** Data: A computer running TMSComm or any other data device that uses a communications protocol provided by Pneumercator to communicate to the TMS.  
--- Not available  
**tTy** TTY: A Teletype style data dump to any device capable of receiving this text only broadcast.  
**nPAGEr** Numeric Pager: Used to send a page to a numeric pager. The telephone number and the page would all be entered in the 21 digit dial-out string.

<b>Cr tH d iRL</b>	<u>Critical High Product – Dial-Out</u> : Defines if the TMS initiates a dial-out for a Critical High Product Set Point. Entry Type: Select List Range Limits: (Yes, No) Default/Initialized value: <b>no</b>
<b>H iH i d iRL</b>	<u>High High Product – Dial-Out</u> : Defines if the TMS initiates a dial-out for a High High Product Set Point. Entry Type: Select List Range Limits: (Yes, No) Default/Initialized value: <b>no</b>
<b>H iGh d iRL</b>	<u>High Product – Dial-Out</u> : Defines if the TMS initiates a dial-out for a High Product Set Point. Entry Type: Select List Range Limits: (Yes, No) Default/Initialized value: <b>no</b>
<b>Lo d iRL</b>	<u>Low Product – Dial-Out</u> : Defines if the TMS initiates a dial-out for a Low Product Set Point. Entry Type: Select List Range Limits: (Yes, No) Default/Initialized value: <b>no</b>
<b>LoLo d iRL</b>	<u>Low Low Product – Dial-Out</u> : Defines if the TMS initiates a dial-out for a Low Low Product Set Point. Entry Type: Select List Range Limits: (Yes, No) Default/Initialized value: <b>no</b>
<b>Cr tLd iRL</b>	<u>Critical Low Product – Dial-Out</u> : Defines if the TMS initiates a dial-out for a Critical Low Product Set Point. Entry Type: Select List Range Limits: (Yes, No) Default/Initialized value: <b>no</b>
<b>thFt d iRL</b>	<u>Theft – Dial-Out</u> : Defines if the TMS initiates a dial-out for Theft of Product. Entry Type: Select List Range Limits: (Yes, No) Default/Initialized value: <b>no</b>
<b>cc d iRL</b>	<u>Contact Closure – Dial-Out</u> : Defines if the TMS initiates a dial-out for an active Contact Closure Input. Entry Type: Select List Range Limits: (Yes, No) Default/Initialized value: <b>no</b>
<b>SEnS d iRL</b>	<u>Sensor – Dial-Out</u> : Defines if the TMS initiates a dial-out for an active Sensor Input. Entry Type: Select List Range Limits: (Yes, No) Default/Initialized value: <b>no</b>
<b>Err d iRL</b>	<u>System Error – Dial-Out</u> : Defines if the TMS initiates a dial-out for any System Error/Event. Entry Type: Select List above Range Limits: (Yes, No) Default/Initialized value: <b>no</b>

- Inventory Dial-Out***      Inventory – Dial-Out: Defines if the TMS initiates a dial-out at the scheduled time for any new entries in the Inventory Log.  
Entry Type: Select List  
Range Limits: (Yes, No)  
Default/Initialized value: **no**
- Inventory Hours***      Inventory – Dial-Out: Defines if the time at which the TMS checks for any new entries in the Inventory Log and initiates a dial-out, if enabled above.  
Entry Type: 4 digit numeric hours, minutes  
Range Limits: 00'00 – 23'59  
Default/Initialized value: **00' 00**
- Return***      Return  
\*Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the CONFIG submenu showing DIAL OUT.  
  
\*Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the DIAL OUT menu showing TEL LOCAL.

### 3.3 CLOCK

```
ACCESS      LOG
            CONF 9
            [ locl
            in tk dAtA
            rEturrn
```

In view mode depressing TEST button first, then MODE and holding both buttons momentarily will increment the TMS into the ACCESS MODE displaying the main menu beginning as follows with LOG. Pressing the EDIT (TEST) button again would cause LOG to blink. Once LOG is blinking, press the ▲ (TEST) button twice to go to the CLOCK menu. Once CLOCK is blinking, pressing the ► (MODE) button will enter the CLOCK menu revealing the DATE.

The CLOCK menu is used to review or edit system clock data.

**Note:** Two types of entries require the user to input programming data when configuring the TMS menus. It is mentioned here, to help the user interpret data displayed in the CONFIG menus. This information below will be explained again in the CLOCK section of the manual.

**Entry Type:** Either a numeric value or a list of choices designated by the system.

**Range Limits:** Selects and enters a numeric value within a fixed boundary, set by the system.

**[ locl**      Clock: The CLOCK menu provides access to the system date, time, and day of the week. All scheduled tasks depend on the system clock to function.

**nn-dd-yy**      Date (MM/DD/YY): Represents the current local date.  
 Entry Type: 6 digit numeric, months, days, years  
 Range Limits: Any valid date. Year is entered as a two digit value.  
 Sample value: **06-22-11** (Represents June 22, 2011)

**HHnnSS**      Time (HH'MM'SS): Represents the current local time in 24-hour format.  
 Entry Type: 6 digit numeric hours, minutes, seconds  
 Range Limits: Any valid time in 24-hour format.  
 Sample value: **00' 00' 00** (Represents 12:00:00AM or midnight)

**dAY**      Day Of The Week: Represents the current day of the week.  
 Entry Type: select list  
 Range Limits: N/A  
 TMS listed options include:  
 Item List:      **Sun** Sunday      **Mon** Monday      **Tue** Tuesday  
                  **Wed** Wednesday      **Thu** Thursday      **Fr** Friday      **Sat** Saturday

**rEturrn**      Return  
 \*Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the ACCESS submenu showing CLOCK.

\*Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the CLOCK menu showing MM-DD-YY.

### 3.4 INIT DATA

**ACCESS**      **Lo9**  
                   **CONF .9**  
                   **[ locT**  
                   **in it dAtA**  
                   **rEturN**

In view mode depressing TEST button first, then MODE and holding both buttons momentarily will increment the TMS into the ACCESS MODE displaying the main menu beginning as follows with LOG. Pressing the EDIT (TEST) button again would cause LOG to blink. Once LOG is blinking, press the ▲ (TEST) button three times to go to the INIT DATA menu. Once INIT DATA is blinking, pressing the ► (MODE) button will enter the INIT DATA menu revealing INIT DATA.

**The INIT DATA menu is a command menu used to initialize the selected data.**

**in it dAtA**      A command that provides the ability to initialize the selected data to the factory default settings. This can be useful if there any suspicion of corrupted data or simply to provide a clean starting point for the system. Once the data to be initialized is selected, pressing the ► (MODE) button will initialize that area in memory and return the display to showing NONE.  
 Item list:  
**nonE** None: No data selected to initialize. The starting point for the command menu.  
**InuEntorY** Inventory Log  
**dEL uErY** Delivery Log  
**SALES** Sales Log  
**tHEFTS** Thefts Log  
**OrdrErS** Product Order Log  
**AlArms** Alarms Log  
**EvEntS** Events Log  
**ALL LoGS** All Logs: Initializes all of the system Logs  
**CONF .9** Configuration: Initializes all Configuration data. DO NOT use this unless the Configuration data is no longer needed.  
**ALL** All: Initializes all system Logs and Configuration data. DO NOT use this unless the all of this data is no longer needed.  
**rEturN** Return: Command to return to the INIT DATA sub menu.

**rEturN**      Return  
 \*Pressing the EDIT (TEST) button at RETURN decrements the TMS back to the ACCESS submenu showing INIT DATA.

\*Holding the STEP (MODE) button until one TMS beep at RETURN advances the TMS to the top of the INIT DATA menu showing INIT DATA.

**APPENDIX A**

**TMS CONSOLE ALARM & EVENT CONDITIONS TABLES**

**Alarm Conditions:**

The following alarm conditions are recorded in the **Alarm Log**. Alarm conditions are also user programmable to auto-dial out upon alarm.

**Leak and Setpoint** alarms will produce both audible and visual LED annunciators until acknowledged via Front panel or Edit enable buttons. Visual LED conditions will continue until the specific leak or setpoint conditions are corrected.

**Theft alarms** will produce an audible annunciator and appear on the TMS display showing a theft message condition across the display. Theft alarms can only be acknowledged via the **Edit enable** button. The displayed message will continue until the condition is corrected.

**CC and SENSOR alarms** will produce an audible annunciator and appear on the TMS display showing a CC or SENSOR alarm message across the display. The audible annunciator can be acknowledged via Front panel or Edit enable buttons. The CC or SENSOR displayed message will continue until the condition is corrected.

Alarm Description					
Display Only		Display and Computer Format			
Status	Detail	Description	Item ID	Name	Notes
SP1	n/a	PRODUCT SETPOINT #1 ALARM	tank #	SetPoint assigned to LED in HEADER menu	Meets or exceeds the programmed product SetPoint. Factory default value is for a HIGH HIGH alarm at or above 95% of Gross Volume.
SP2	n/a	PRODUCT SETPOINT #2 ALARM	tank #	SetPoint assigned to LED in HEADER menu	Meets or exceeds the programmed product SetPoint. Factory default value is for a HIGH alarm at or above 90% of Gross Volume.
SP3	n/a	PRODUCT SETPOINT #3 ALARM	tank #	SetPoint assigned to LED in HEADER menu	Meets or exceeds the programmed product SetPoint. Factory default value is for a LOW alarm at or below 20% of Gross Volume.
Theft	n/a	THEFT ALARM	tank #	n/a	Theft of product from the tank
CC	Open	CONTACT CLOSURE ALARM - OPEN	cc #	Contact Closure Name	Device wired to CC Input is in alarm
CC	Closed	CONTACT CLOSURE ALARM - CLOSED	cc #	Contact Closure Name	
Sensor	Open	POINT SENSOR ALARM - OPEN	sensor #	Sensor Name	Point level (High, Low, etc.) sensor is in alarm
Sensor	Closed	POINT SENSOR ALARM - CLOSED	sensor #	Sensor Name	
Sensor	Open	LEAK SENSOR ALARM - OPEN	sensor #	Sensor Name	Non-discriminating leak sensor is in alarm
Sensor	Closed	LEAK SENSOR ALARM - CLOSED	sensor #	Sensor Name	
Sensor	Product	LEAK SENSOR ALARM - PRODUCT	sensor #	Sensor Name	Discriminating leak sensor is in alarm
Sensor	Water	LEAK SENSOR ALARM - WATER	sensor #	Sensor Name	

Note: ISCC or Intrinsically Safe Contact Closure is synonymous with Leak/Pt. Level Sensor



**Error Conditions:**

All Error conditions are recorded in the Event Log. Error conditions are also user programmable to auto-dial out upon alarm. Errors will produce an audible alarm and appear on the TMS display showing the specific error condition and code number. Errors conditions can only be silenced by acknowledging the Front panel buttons. The displayed error message will continue until the condition is corrected.

Event Description for Errors				
Error #	Description	Item ID	Name	Notes
10	PROBE LEVEL	probe #	n/a	Unintelligible signal received from probe
11	PROBE TIMEOUT	probe #	n/a	No signal being detected from probe
13	PROBE TEMPERATURE	probe #	n/a	Unintelligible signal received from probe
20	SENSOR FAULT - SHORT CIRCUIT	sensor #	sensor name	Wiring fault with all sensors but ES825-200F
21	SENSOR FAULT - OPEN CIRCUIT	sensor #	sensor name	
22	SENSOR FAULT	sensor #	sensor name	Wiring fault with ES825-200F

Note: ISCC or Intrinsically Safe Contact Closure is synonymous with Leak/Pt. Level Sensor

**Warning Conditions:**

With the exception for a Power Failure, Warning 21 (*Power Fail Warning*), warning conditions are not logged in the **Event Log**. Warnings will produce an audible alarm and appear on the TMS display showing the specific warning condition and code number. Warning conditions may be user acknowledged via Front panel buttons.

Event Description for Warnings				
Warning #	Description	Item ID	Name	Notes
1	MODEM - INITIALIZATION ERROR	n/a	n/a	Check the phone line and then the modem for trouble
2	MODEM - COMMAND ERROR	n/a	n/a	
3	MODEM - RESPONSE TIMEOUT ERROR	n/a	n/a	
4	MODEM - NO CARRIER	n/a	n/a	
5	MODEM - COMMUNICATIONS ERROR	n/a	n/a	
6	MODEM - NO DIALTONE	n/a	n/a	
7	CONFIG - TANK	tank #	n/a	Checksum error in the referenced section of memory. Review the configuration and resave the configuration to the TMS. If the warning persists there may be a memory failure in the TMS
8	CONFIG - PROBE	probe #	n/a	
9	CONFIG - HEADER	n/a	n/a	
10	CONFIG - RELAY/TANK	tank #	n/a	
11	CONFIG - RELAY/CC	cc #	n/a	
12	CONFIG - RELAY/SENSOR	sensor #	n/a	
13	CONFIG - RELAY/SITE	n/a	n/a	
14	CONFIG - RELAY/MODE	relay #	n/a	
15	CONFIG - CC	cc #	n/a	
16	CONFIG - SENSOR	sensor #	n/a	
17	CONFIG - INVENTORY	n/a	n/a	
18	CONFIG - THEFT	n/a	n/a	
19	CONFIG - MODEM	n/a	n/a	
20	CONFIG - DIALOUT	dialout ch. #	n/a	
21	POWER FAIL DETECTED	n/a	n/a	Reported after a 1-2 minute loss of power when the power has been restored.
23	TANK ID LENGTH	tank #	n/a	A double digit tank ID has been assigned to a tank with a capacity of one million gallons or greater. The TMS requires these ID's be 1 digit to accommodate the length of the volume reading.
28	FRONT END COMMUNICATION	n/a	n/a	Indicates a communications failure on the Main Board. Power off the TMS1000N, wait at least two seconds, and power on the TMS1000N. If the Warning persists, the Main Board, P/N 900699-1, will need to be repaired or replaced.

Note: ISCC or Intrinsically Safe Contact Closure is synonymous with Leak/Pt. Level Sensor

**Information Messages:**

Information messages convey statuses generally considered to be advisory. These types of messages appear only on the TMS display until acknowledged via Front panel buttons. They do not generate audible/visual alarms, and are not captured in any of the system logs.

Event Description for Information Messages				
Info #	Description	Item ID	Name	Notes
2	UNGAUGEABLE LEVEL	tank #	n/a	TMS informs user that the product float for the indicated tank has reached a float collar stop or its minimum gaugeable level. Because the stop is some distance above the actual tank bottom, an alternating minimum gaugeable level and the message "Low Product" will be displayed. This condition is usually associated with probes requiring "Special Tank TOP mounting". These minimum gauging points are programmed for all enabled tanks in the changed in the <b>Config Tank Menu</b> .

**APPENDIX B: MAINTENANCE**

This maintenance documentation presumes that the system to be tested has been installed in accordance with all current documentation for the system and has been started up by a factory certified technician. If you feel that this service has not been performed, adequately or otherwise, please contact your local authorized Pneumercator service provider to make the necessary arrangements.

The TMS1000N will be able to detect many conditions, including memory failure within the system, probe communication issues, and sensor wiring faults (when equipped with a Pneumercator fault detecting sensor). Reviewing and addressing any Alarm or Event conditions displayed on the TMS would be the best place to start for determining the proper functioning of the system. Inspection of all cabling for cracking or swelling and evaluating the condition of the splices will help to maintain a properly working system.

Before connecting or disconnecting ANY cables, power off the system. Once the cabling changes are complete, the system can be powered on.

While annual inspection is considered to be a good general practice, it may be required by regulation or application to perform inspections more frequently.

The following table includes a model specific list of additional points of inspection.

Model(s)	Check points
TMS	<ol style="list-style-type: none"> <li>1. Press the TEST button to verify all integrated lights and horn are functioning</li> <li>2. Take a stick reading of the tank and confirm that the TMS Level Reading matches the stick reading. If there is a discrepancy, perform the float height offset procedure as outlined in the Quick Startup Guide.</li> </ol>
Rigid Probes (MP55xS)	Remove the probe to verify there is no damage to the floats and no residue buildup on the floats or probe shaft. Clean as necessary.
ES825-300FL (non-discriminating)	Remove and inspect the sensor for physical damage. Test the sensor by placing in a nonreflective water-filled container shielded from ambient light. Verify the alarm received on the system display is as expected. Clean sensor to remove any contaminants.
ES825-400FL (discriminating)	Remove and inspect the sensor for physical damage. Test the sensor by placing in a nonreflective water-filled container shielded from ambient light. Verify the alarm received on the system display is as expected. Repeat using a container filled with product. Clean sensor to remove any contaminants.
Float switch sensors: Includes: LS600, LS600LD, LS610, RSU800	Remove and inspect the sensor for physical damage or debris that may obstruct the movement of the float. Test the sensor by manipulating the float. Verify the alarm received on the system display is as expected. Clean sensor to remove any contaminants, as necessary.

<p>HS100ND</p>	<p>Refer to the documentation supplied with the sensor for proper testing procedures. Contact Pneumercator for additional information.</p>
<p>Remote Alarms: Includes all RA and select LC1000 systems</p>	<p>Press the Test button associated with the remote alarm. It is also recommended to simulate an alarm on the controlling system to verify the operation of the remote alarm.</p>

**APPENDIX C****TMS Main Board Dip Switch Settings**

The TMS1000N is equipped with a Main System Board that is supplied with DIP switches that have been factory set. Switches are housed in a small rectangular Red enclosure and are numbered 1-4.

**Note:** As always, any mechanical or electrical modifications to TMS system (including switch settings), probe, sensor, or other accessories requires the console to be powered-down.

**Dip Switch Function/Condition:**

**SW1:** Edit Enable – With the rocker arm in the OPEN position, this switch activates the **Edit Enable** feature. This allows the user to make any necessary programming changes via the front panel buttons.

**SW2:** Unused – Factory set at Closed.

**SW3:** Motion Band Symbol – With the rocker arm in the OPEN position, this switch activates the System **Motion Band Symbol**, producing a lower case horizontal line to the right of the Tank ID #. This visual display represents movement of product in the tank for either Deliveries, Sales, or Thefts. Any of these conditions will be logged as a function of the Motion Band sensitivity setting, which is user programmed in the CONFIG PROBE menu. This symbol will disappear from the display within 3 minutes after the tank contents has settled and stopped moving. The motion band symbol will also be present on system power up. The audible annunciator will not be activated during this condition.

**SW4:** Communication Security – With the rocker arm in the OPEN position, this switch activates the TMS **Communication Security** feature. This feature is used when a pass code is desired to prevent unauthorized access when communicating with the TMS. This switch works in conjunction with the Security setting found in the Header menu.



# PNEUMERCATOR TMS SERIES

## LIMITED WARRANTY

### TMS Series

**Pneumercator**, here and after referred to as **PCO**, warrants its **TMS Series** family of products to be free of defects in material and workmanship for a period of **Twelve (12) months** from date of installation or **Fifteen (15) months** from date of invoice, whichever comes first.

During the warranty period on the **TMS Series**, **PCO**, or factory third party independent representatives will repair or replace the product at the location where it is installed at no additional cost to the customer.

Packages must be inspected upon receipt for damage, missing parts, and/or manuals. **PCO** must be contacted by telephone immediately with a description of damaged or missing parts so replacements can be sent. Written details must be sent within **thirty (30) days**.

Pneumercator will not be responsible for shipping charges incurred by the customer.

Warranty repair coverage invoices will be paid if **all** the following conditions are met:

- PCO has acknowledged and authorized warranty work to be done by issuing a *Warranty Repair Number*.
- Start-up Service technician has been trained by PCO
- Warranty start-up form has been submitted to PCO
- Technician fills out and submits a PCO "Service Report"
- Parts (if any) used are returned to PCO with a proper WRGA (*Warranty Return Goods Authorization*)
- Returned parts are found to be defective.

Repair time will be paid according to PCO document "Standard Warranty Labor Charge Schedule"

If the Warranty Registration/Start up Check List has been completed and returned on file with the factory and the product is installed in accordance with the specific PCO Installation Product Manual, PCO will activate and meet warranty criteria as described above. Warranty criteria shall be voided if any product has been subjected to misuse, negligence, damage from acts of nature (lightning, wind, rain, etc.) or is in violation of the products design intent, disregard to warnings, instructions, modified or repaired by unauthorized personnel or improperly installed. Given that the third party independent contractor has installed the equipment in accordance with the specific product instruction manual, and followed all precautions, PCO will fulfill the terms stated in our warranty obligation.

Under no circumstances does the warranty provide a remedy in excess of the equipment. No other expressed or implied warranty is given by PCO. PCO shall not be liable for consequential damages or any expenses incurred by the user.

Distributed by:

 **PNEUMERCATOR**  
Liquid Level Control Systems

1785 Expressway Drive North, Hauppauge, NY 11788  
(631) 293-8450 Fax (631) 293-8533