
IMPORTANT! TMS2000 SENSOR WIRING INSTRUCTIONS

IDENTIFY THE TYPE OF SENSOR(S) TO BE INSTALLED. WIRING MUST BE TERMINATED ON THE TERMINALS INDICATED BELOW TO ENSURE CORRECT OPERATION.



Questions? Contact Technical Support at (800) 209-7858

PNEUMERCATOR
Liquid Level Control Systems

* RED IS COMMON GROUND WIRE

Bulletin 173 Rev. A (11/01/07)

S

=BLK =

Page 1 of 1