
## WIRING DRAWING - TMS2000W AND TMS4000W (Wireless)

## TMS2000W1 and TMS4000W1 - (See Page 2 for W2)



## **▲** IMPORTANT NOTES - READ CAREFULLY BEFORE INSTALLATION

- 1. CONSOLE MOUNTING: TMS AND MWR200 (IF APPLICABLE) SHOULD NEVER BE LOCATED IN THE HAZARDOUS CLASSIFIED AREA. CAREFUL CONSIDERATION SHOULD BE GIVEN TO LOCATING THE TMS OR MWR200 FOR OPTIMUM RADIO PERFORMANCE.
- 2. MAXIMUM DISTANCE: IT IS DIFFICULT TO SPECIFY A MAXIMUM TRANSMISSION DISTANCE THAT COVERS ALL APPLICATIONS DUE TO THE VARIABILITY OF INSTALLATIONS. THIS IS ESPECIALLY TRUE OF UST INSTALLATIONS, WHERE MAXIMUM RANGE MAY BE LIMITED TO AS LITTLE AS 100 TO 200 FEET, WHILE AST INSTALLATIONS MAY SEE RANGES UP TO 1000 FEET USING THE STANDARD MONOPOLE ANTENNA, OR UP TO SEVERAL MILES USING A DIRECTIONAL ANTENNA. OTHER FACTORS INCLUDING LINE-OF-SIGHT OBSTACLES AND OTHER RADIO FREQUENCY SOURCES MAY ALSO IMPACT TRANSMISSION DISTANCE.

Questions? Contact Technical Support at (800) 209-7858



50443 Rev. C (11/14/17)

Page 1 of 2

